
5.5 INPUT SURVEY DATA

INITIAL SETUP:

Tools and Special Tools

None

References

5 System Configuration WP
6.2 Calibration WP

Materials/Parts

None

Equipment Condition

5.4 GTU Setup WP Completed
Equipment Powered On
Generator or Shore power applied

Personnel Required

1 Technician

GENERAL INFORMATION

- This procedure is for initial setup and if any antenna is moved. Survey data captured in section 5.1 Equipment Survey WP will be used to complete this procedure.
- The following procedure will need to be repeated for the second rack if system is configured with dual racks.
- Switch to the rack being configured on the Remote Control Unit (RCU).

Input Survey Data

1. At the Maintenance Interface main window, click on "SYSTEM SETUP" button.
2. At the System Setup main window, click on the "Survey" button.

NOTE

- Use survey data sheet to complete the following data entry.
 - Current settings are factory default.
3. Input the range and azimuth Angle for the ASA Reference Antenna; ATA; Cal/BIT Antenna; and Interrogation Antenna.
 - a. Input the ASA Reference antenna range, azimuth angle and elevation angle.
 - b. Input the ESA Reference antenna range, azimuth angle and elevation angle.
 - c. Input the ATA antenna range, azimuth angle and elevation angle.
 - d. Input the Cal/BIT Antenna, antenna range and azimuth angle.
 - e. Input the Interrogation Antenna range and azimuth angle.
 4. Input the ESA separation from reference antenna for the Low, Medium, and High antennas.
 5. Input the tower base plate separation from the reference antenna phase center.

6. Input the MSL altitude and runway heading.

NOTE

Information is site specific and pulled from pre-site survey.

7. Press "OK" to close the Survey data.
8. Press "Close" to exit "System Setup" menu and return to the MI main menu.
9. Record verification that survey data was entered in the System Configuration Check Sheet.

END OF TASK
