





IO expanders





Use Open-drain config for interrupt

















Ecran: https://www.waveshare.com/wiki/File:2.7inch_e-Paper_HAT_Schematic.pdf

Note: display connector pin assignment is contrary to that of display datasheet, because connector flips and connects to bottom of PCB

4

Sheet name	Default Sheet Name	
Project name	OpenIMU	
Contact	V-P.Rheaume@USherbrooke.ca	
Rev 1.0 D	ate 2018-06-04 Sheet 8 of 8	