

ATS282X

RF测试指南

Latest Version: 3.0

2016-03-25



1声明

Disclaimer

Information given in this document is provided just as a reference or example for the purpose of using Actions' products, and cannot be treated as a part of any quotation or contract for sale.

Actions products may contain design defects or errors known as anomalies or errata which may cause the products' functions to deviate from published specifications. Designers must not rely on the instructions of Actions' products marked "reserved" or "undefined". Actions reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

ACTIONS DISCLAIMS AND EXCLUDES ANY AND ALL WARRANTIES, INCLUDING WITHOUT LIMITATION ANY AND ALL EXPRESS OR IMPLIED WARRANTIES OF MERCHANTABILITY, ACCURACY, SECURITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND AGAINST INFRINGEMENT OF INTELLECTUAL PROPERTY AND THE LIKE TO THE INFORMATON OF THIS DOCUMENT AND ACTIONS PRODUCTS.

IN NO EVENT SHALL ACTIONS BE LIABLE FOR ANY DIRECT, INCIDENTAL, INDIRECT, SPECIAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION FOR LOST OF DATA, PROFITS, SAVINGS OR REVENUES OF ANY KIND ARISING FROM USING THE INFORMATON OF THIS DOCUMENT AND ACTIONS PRODUCTS. REGARDLESS OF THE FORM OF ACTION, WHETHER BASED ON CONTRACT; TORT; NEGLIGENCE OF ACTIONS OR OTHERS; STRICT LIABILITY; OR OTHERWISE; WHETHER OR NOT ANY REMEDY OF BUYER IS HELD TO HAVE FAILED OF ITS ESSENTIAL PURPOSE, AND WHETHER ACTIONS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR NOT.

Actions' products are not designed, intended, authorized or warranted for use in any life support or other application where product failure could cause or contribute to personal injury or severe property damage. Any and all such uses without prior written approval of an Officer of Actions and further testing and/or modification will be fully at the risk of the customer.

Ways of obtaining information

Copies of this document and/or other Actions product literature, as well as the Terms and Conditions of Sale Agreement, may be obtained by visiting Actions' website at: http://www.actions-semi.com or from an authorized Actions representative.



Trademarks

The word "Actions" and the logo are the trademarks of Actions Semiconductor Co., Ltd, and Actions (Zhuhai) Technology Co., Limited is authorized to use them. Word "炬芯" is the trademark of Actions (Zhuhai) Technology Co., Limited. Names and brands of other companies and their products that may from time to time descriptively appear in this document are the trademarks of their respective holders, no affiliation, authorization, or endorsement by such persons are claimed or implied except as may be expressly stated therein.

Rights Reserved

The provision of this document shall not be deemed to grant buyers any right in and to patent, copyright, trademark, trade secret, know how, and any other intellectual property of Actions or others.

Miscellaneous

Information contained or described herein relates only to the Actions products and as of the release date of this publication, abrogates and supersedes all previously published data and specifications relating to such products provided by Actions or by any other person purporting to distribute such information.

Actions reserves the rights to make changes to information described herein at any time without notice. Please contact your Actions sales representatives to obtain the latest information before placing your product order.

Additional Support

Additional products and company information can be obtained by visiting the Actions website at: http://www.actions-semi.com

支持:

如欲获得公司及产品的其它信息,欢迎访问我公司网站: http://www.actions-semi.com

版本: V1.0 第2页

2 目 录

1	声 明	1
2	2目 录	3
	8 引言	
	3.1 版本历史	
	3.2 编写目的	3
4	Ⅰ 测试准备	4
5	5 定频测试	7
6	3 跳频测试	7
7	7 LE Test	8
8	3 BR/EDR测试	10

3 引言

3.1 版本历史

日期	版本号	注释	作者
2015-10-10	1.0	建立初始版本	成展广
2016-01-05	2.0	增加用蓝牙综测仪测试 LE 和 BR/EDR 的说明	成展广
2016-03-24	3.0	配合新发布 SDK 包,定频工具和 FT_Mode 宏定义位置更新	成展广

3.2 编写目的

本文档主要介绍如何进行芯片或模块的 RF 定频测试,适用于 ATS282X 系列芯片,如 ATS2823,ATS2823B,ATS2825,ATS2829 等等。



4测试准备

1. FCC test 时的硬件接线:

ATS282X 的 GPIOA21, 连接到 PC 端串口工具的 RX, ATS282X 的 GPIOA22, 连接到 PC 端串口工具的 TX, GND 共地连接,

VCC, PC 端的串口工具若是 RS232 串口工具则需要连接 VCC 供电,如果是 USB 转串口工具则不需要接 VCC。

2. 待测试机器(DUT)要烧录能进入测试模式的定频测试固件,该测试固件的制作方法是在 case\ap\ap_manager\manager_main.c 中将注释掉的 #define FT_MODE 宏打开,然后重新编译打包生成固件。


```
UltraEdit - [D:\US282A\SVN_ALL\SVN_M\GL5106\trunk\US282A\case\ap\ap_manager\manager_main.c]

| Galle | Edit | Search | Insert | Project | View | Format | Column | Macro | Scripting | Advanced | Window | Help |
| Sala | Ala 
                     manager_main.c 🗴
                                                                                              10 -
            11 □ /*!
                            * \file
                                                                     manager main.c
                            * \brief manager的main函数模块
                           * \author zhangts
* \version 1.0
            14
                           * \date 2011/9/05
******
            17
            18 #include "manager.h
            19 #include <card.h>
            20 #include <sysdef.h>
                          //#define FT MODE OS_STK *plos = (OS_STK *) AP_PROCESS_MANAGER_STK_POS;
           22 //#define FT MODE
            24 INT8U prio = AP PROCESS MANAGER PRIO;
           test_share_info_t *g_p_test_share_info;
           26
                        extern app result e manager message loop(void) FAR ;
           28 extern bool globe_data_init(void) __FAR__;
            30 void system config(void);
            31
            32 typedef void (*handler ker) (void);
```


3. 先给 DUT 上电,再将串口工具接到电脑上,请注意这个上电顺序,以防串口工具影响 DUT 上电开机。



4. 在发布资料包中的 Tool 文件夹中找到 FCC Tool 工具,找到并打开 ACTsBTAPP.exe。软件工具版本请使用最新发布版本。




5. 打开软件后,在软件界面上的 PORT 处选择 PC 与串口工具连接的串口。点击 open,进行连接。Baudrate 默认使用 115200。




Page 5



6. 如果软件 Message 窗口提示连接失败,此时左上角依然显示红色 X,此时请检查① Port 选择是否正确,串口工具和 DUT 接线是否正确;② DUT 工作状态是否正常,如烧录的固件是否正确,BTVCC 电压是否正常等;③ 串口工具是否损坏或者兼容性不好:④ PC 端软件工具运行是否正常,更换 PC 再尝试。



7. 如果连接成功,左上角会显示绿色 O,且 Message 窗口会有连接的相关信息打印:




8. 连接成功后可以进入 Non Link Mode, LE, Hopping 测试。



5 定频测试

Non Link Mode: 手动测试 BR/EDR RF 性能,软件打开后就是默认进入这个模式。在软件界面上按照测试要求设置相关参数后点 **Exec** 即可运行测试。



Channel: 选择发射频道, 0-->2402MHZ, 39-->2441MHZ, 78-->2480MHZ 等。

Packet Type: 发送包类型,包括 DH1/DH3/DH5/2DH1/2DH3/2DH5/3DH1/3DH3/3DH5

PayLoad Type: 发送信息的内容,包括 All '0', All

'1', 0101, 1010, 0x0~0xF, 00001111, 11110000, PRBS9, 其中 PRBS9 表示随机码。

TX Packet Count: 发送包的数量, 0表示无限。

TX Gain Index: 发送功率控制,参数值为0~7,每个相隔3dB,默认为5(1dBm)。如需

要调整可以右键-->Debug-->Enable BT Tx Power Index 。

TX Gain Value: 默认使用 Actions 指定值,无法修改。


Con-Tx: 持续发射模式 Pkt-Tx: 包发射模式 Pkt-RX: 包接收模式

Single Tone: 纯载波测试模式

6 跳频测试


Hopping: 跳频测试,设置 packet type 和 channel 后点 Run 进入测试,请注意 packet type 不能为 NULL。






7 LE Test

①手动测试可以按照测试要求设置后点 Start 开始测试。





②用蓝牙综测仪自动化测试可以点 HCI Reset 初始化,初始化成功后把串口转接到蓝牙综测仪上进行连接并测试即可。**注意:蓝牙综测仪串口波特率也要设置为 115200。**






8 BR/EDR 测试

BR/EDR 测试,要用蓝牙综测仪测试 BR/EDR 可以点 Test Mode 进入测试模式,然后用蓝牙综测仪去查询连接并进行测试即可。

注意:测试 TX 项目时要用 TX Mode,不能使用 Loopback。





炬芯 (珠海) 科技有限公司

地址: 珠海市唐家湾镇高新区科技四路 1号 1#厂房一层 C区

电话: +86-756-3392353 传真: +86-756-3392251

邮政编码: 519085

网址: http://www.actions-semi.com

电子邮件 (业务): mp-sales@actions-semi.com

(技术支持): mp-cs@actions-semi.com