

Paramétrage startup wizard







Regulation

Select control loop structures.

Sensors




X4 - Digital Hall sensors & X6 - Analog incremental encoder (sin/cos)



Units

Select controller units.





Digital Inputs

Enter digital input functionalities and characteristics.

Input	Functionality	Polarity
Digital input 1	None	High active
Digital input 2	Negative limit switch	High active
Digital input 3	Positive limit switch	High active
Digital input 4	None	High active
High-speed digital input 1	None	High active
High-speed digital input 2	None	High active
High-speed digital input 3	None	High active
High-speed digital input 4	None	High active

High-speed digital inputs are configured for the sensor on connector X6.

Digital Outputs

Enter digital output functionalities and characteristics.

Output	Functionality	Polarity
Digital output 1	General purpose A	High active
Digital output 2	None	High active
High-speed digital output 1	None	High active

High-speed digital output 1 is configured for the sensor on connector X6.