Yummy Gummy quick reference · Step Mother

Firmware 1.2.0 • Follows the host’s MIDI clock • Glide + Wave + Play switches to StepBro and back • Pads 1–16

NOTE
Tap: Note page
Double-tap: arm recording
Tap again: disarm

PATTERN
Tap: steps
Hold + slot: select
2× tap: chain
+ Glide: copy
+ Function: erase
Hold + knob: transpose

GLIDE
Pattern page: hold + step to toggle slide

ACCENT
Pattern page: hold + step: accent
+ Glide + empty step: tie

KNOB
Normally: cutoff
Function: selected value
Hold step, stopped: pitch
Hold Scale: root

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

PAD ORDER
Left to right, top to bottom
1–16

WAVE
Tap: saw / square
Hold + knob: volume
Glide + Wave + Play: StepBro

FUNCTION
Tap: parameters
+ Play: MIDI diagnostics

PLAY
Mute / unmute on the beat
Also while the host is stopped

NOTE page

Tap to select and hear · Poly: press pads together

C	C♯	D	D♯
E	F	F♯	G
G♯	A	A♯	B
C	Scale hold	Oct −	Oct +

Scale + pads 1–6
Chromatic, minor, major, minor pentatonic, Phrygian, blues. Programmed notes follow; switching back restores them.

Scale + knob
Root C–B; top-right pad in the letter display means sharp.

Out-of-scale pads play the nearest scale note. Double-tap Note to record; hold notes to record ties.

FUNCTION page

Tap a pad, then turn knob · Cutoff selected on entry

Cutoff	Resonance	Env Mod	Decay
Accent	Delay Amount	Delay Time 6 synced divisions	Distortion Mix · hold: Drive
Random tap again: roll	Tune ±7 semitones	Swing 50–75%	Length 1–16 steps
MIDI Channel tap, then turn knob	MIDI Out lit = on · default off	MIDI Lead tap, then turn knob	Mono / Poly tap to toggle

Double-tap 1–8: record knob moves · Function + pad: clear.
MIDI Channel / Lead: tap the pad, then turn the knob.
Hold Distortion + pad 1 / 2: soft clip / sine shaping.

PATTERN page

Pads = steps 1–16 · Brightest = playhead

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Tap empty step / tap occupied step
Place selected note or chord / clear. Keep taps under 0.4 s.

Hold step + knob, while stopped
Audition and move the note or chord through the scale.

Accent / Glide / both + step: accent / slide / tie. A new tie needs an empty step after a note or tie.

HOLD PATTERN view

Pads = pattern slots 1–16

Select or chain
Hold Pattern + slot: select. Double-tap Pattern, tap slots: chain (up to 64, repeats allowed); Pattern, Note or Function ends it.

Copy / erase
Hold Pattern + Glide: source, then destination.
Hold Pattern + Function: tap slot to erase. No undo.

Transpose
Hold Pattern + knob: −12 to +12 semitones.

Knob pickup: cross the saved value before it changes.
Poly: up to 4 notes share the filter and envelopes.
Follows host clock only: send it to Step Mother.
StepBro level: Shift + Mute + pad 2 / 3 mutes MIDI / audio.

SAVE
Automatic ~1.5 s after a change, all stopped, keys released.

USB AUDIO + MIDI
Step Mother · 48 kHz audio · MIDI ch 2, on.

STARTUP
Glide + Function at power-up: install mode (StepDaddy).

FIRMWARE
1.2.0 · Yummy Gummy and StepBro in one.