
FROM: Topic 7.3, View Pane		
Slot Sheet view	The <b>Slot Sheet</b> view is used to view all of the "slots" of a component. Here slots may be added, deleted, renamed, reordered or configured.	
Slots	Niagara components are defined as a collection of "slots."  These define both the characteristics (Properties) of a component and how those components will behave (Actions) when a user invokes a command or an event occurs.	
Slot attributes	SLOT ATTRIBUTES  Type Name Definition Flags Facets	
	Slots are either "Frozen" or "Dynamic." FROZEN SLOTS Frozen slots CANNOT be edited. They are hard-coded so that they are consistent across all instances of a specified slot type.	
	DYNAMIC SLOTS  Dynamic slots may be added, deleted, renamed or reordered during runtime  – they CAN change.  There is no limit on the number of dynamic slots to a component.	
Flags	Flags modify how an object is presented or <u>behaves</u> , such as:       Read-only     Operator allowed     Hidden	
Facets	Facets determine how an object is <u>displayed</u> in the station:    Begineering units & decimal precision (for numeric points)  Descriptive value (state) text (for boolean & enum points)	
Working with components	COMPONENT ACTION	SLOT SHEET
	Add new slots on components	х
	Delete existing slots on components	х
	Rename components* and slots on components	х
	Reorder components*	х
	* When viewing components in a container, these "child" components appear as slots of the "parent" component (container).	

From CBT course Niagara<sup>AX</sup> Technical Certification Program, Tridium, Inc. Copyright © 2009


# Right-click pop-up menu

Most of the component interactions you will encounter on the **Slot Sheet** view will be accomplished using the **right-click pop-up menu**.



#### Adding slots


To add a slot to a component, <u>right-click</u> on a slot or on the blank space at the bottom of the Slot Sheet. From the pop-up menu, select "**Add Slot**." Configure the slot using the **Add Slot dialog** box. A new slot appears at the end of the table.



#### Deleting slots

To delete a slot, <u>right-click</u> on any **dynamic slot** (as indicated in the Definition column) and select "**Delete**" from the pop-up menu. Dynamic slots may be added, deleted, renamed, and reordered during runtime - they can change. Frozen slots CANNOT change; they are hard-coded so that they are consistent across all instances of a specified slot type.

<u>NOTE</u>: The "Delete" selection in the pop-up menu is grayed-out for Frozen slots.



## Renaming slots To rename a slot, right-click on any dynamic slot (as indicated in the Definition column). NOTE: The "Rename" selection in the pop-up menu is grayed-out for Frozen slots. → Add Slot Ctrl+A Copy Copy Ctrl+C Delete Rename Slot Ctrl+R Config Flags Config Facets Display Name Bajadoc for Type From the pop-up menu, select "Rename Slot." Type the new name in the Rename dialog box. The new name now appears for both the "Name" and "Displayed Name" columns. Changing slot You can rename the Display Name of any frozen or dynamic slot by rightclicking and selecting "Display Name" from the pop-up menu, OR by display names double-clicking the slot to change the display name. Then, type in the desired display name in the dialog box. 🗎 Display Name Display name for "Renamed\_Slot": Renamed Slot Cancel OK To reorder dynamic slots for a component, right-click on any dynamic slot, Reordering slots select "Reorder" from the pop-up menu. Reorder using the "Move Up" and "Move Down" buttons. The new slot order appears. Reorder Damper ⊕ Move Up Link Renamed\_Slot J. Move Down Sort by Name Sort by Type OK Cancel

