
User's Manual



When the NoMaze checkbox is selected all edit fields related to maze parameters are disabled. That is, maze distances, maze areas and angles.

When the OneLeg checkbox is checked, the edit field related to the parameters of the first leg maze are enabled. That is, d_{d1} , d_{m1} , d_{m2} , A_{ma} , A_{m1a} , A_{m1b} , θ_{o1} and θ_{r1} .

When the TwoLeg checkbox is checked, the edit field related to the parameters of the first and second leg maze are enabled. That is all the field for distances, areas and angles are enabled.

