

7.1.6 OUTPUT SOURCES

Output Sources			
0	Not Used	77	Emergency Stop
1	Air Flap Relay	78	Energise To Stop
2	Alarm Mute	79	External Panel Lock
3	Alarm Reset	80	Fail To Start
4	Alt Config 1 Selected	81	Fail To Stop
5	Alt Config 2 Selected	82	Fan Control
6	Alt Config 3 Selected	83	Flex Sensor A High Alarm
7	Alt Config 4 Selected	84	Flex Sensor A High Pre-Alm
8	Alt Config 5 Selected	85	Flex Sensor A Low Alarm
9	Analogue Input A	86	Flex Sensor A Low Pre-Alm
10	Analogue Input B	87	Flex Sensor A OC
11	Analogue Input C	88	Flex Sensor B High Alarm
12	Analogue Input D	89	Flex Sensor B High Pre-Alm
13	Arm Safety On Alarms	90	Flex Sensor B Low Alarm
14	Audible Alarm	91	Flex Sensor B Low Pre-Alm
15	Auto Restore Inhibit	92	Flex Sensor B OC
16	Auto Start Inhibit	93	Flex Sensor C High Alarm
17	Auxiliary Mains Failure	94	Flex Sensor C High Pre-Alm
18	Battery High Volts	95	Flex Sensor C Low Alarm
19	Batter Low Volts	96	Flex Sensor C Low Pre-Alm
20	Call For Scheduled Run	97	Flex Sensor C OC
21	Charge Alt Fail Shutdown	98	Flex Sensor D High Alarm
22	Charge Alt Fail Warning	99	Flex Sensor D High Pre-Alm
23	Close Gen Output	100	Flex Sensor D Low Alarm
24	Close Gen Pulse	101	Flex Sensor D Low Pre-Alm
25	Close Mains Output	102	Flex Sensor D OC
26	Close Mains Pulse	103	Fuel Level High Alarm
27	Combined Mains Failure	104	Fuel Level High Pre-Alarm
28	Maintenance Alm 1,2,3	105	Fuel Level Low Alarm
29	Common Lo/Hi Freq Alm	106	Fuel Level Low Pre-Alarm
30	Combined Lo/Hi Freq Warning	107	Fuel Pump Control
31	Combined Lo/Hi Volt Alm	108	Fuel Relay
32	Combined Lo/Hi Volt Wng	109	Fuel Sensor OC
33	Common Alarm	110	Fuel Tank Bund Level High
34	Common E Trip	111	Fuel Usage Alarm
35	Common Shutdown	112	Gas Choke On
36	Common Warning	113	Gas Ignition
37	Config CAN 1 Active	114	Gen Loading Freq Not Reached
38	Config CAN 10 Active	115	Gen Loading Volts Not Reached
39	Config CAN 2 Active	116	Gen Hi Freq Overshoot Alm
40	Config CAN 3 Active	117	Gen Hi Freq Overshoot Wng
41	Config CAN 4 Active	118	Gen Available
42	Config CAN 5 Active	119	Gen Closed Aux
43	Config CAN 6 Active	120	Gen Excite
44	Config CAN 7 Active	121	Gen High Volts Alarm
45	Config CAN 8 Active	122	Gen High Volts Warning
46	Config CAN 9 Active	123	Gen High Volts Shutdown
47	Coolant Cooler Control	124	Gen Load Inhibit
48	Coolant Heater Control	125	Gen Low Volts Alarm
154	Mains Load Inhibit		
155	Mains Low Freq		
156	Mains Low Volts		
157	Mains Ph Rotation Alarm		
158	Maintenance Alarm 1 Due		
159	Maintenance Alarm 2 Due		
160	Maintenance Alarm 3 Due		
161	Manual Restore Contact		
162	MPU Open Circuit		
163	Negative Ph Sequence Alm		
164	Oil Pressure Sensor OC		
165	Oil Pressure Switch		
166	Open Gen Output		
167	Open Gen Pulse		
168	Open Mains Output		
169	Open Mains Pulse		
170	Over Current IDMT Alarm		
171	Over Current Imm Warning		
172	Over Freq Runaway		
173	Over Freq Warning		
174	Over Speed Runaway		
175	Over Speed Shutdown		
176	Over Speed Warning		
177	Overspeed Delayed Alarm		
178	Overspeed Delayed Wng		
179	Overspeed Overshoot Alarm		
180	Overspeed Overshoot Wng		
181	Preheat During Preheat Timer		
182	Preheat Until Crank End		
183	Preheat Until End Of Safety		
184	Preheat Until End Of Warming		
185	Protections Disabled		
186	Remote Control 1		
187	Remote Control 10		
188	Remote Control 2		
189	Remote Control 3		
190	Remote Control 4		
191	Remote Control 5		
192	Remote Control 6		
193	Remote Control 7		
194	Remote Control 8		
195	Remote Control 9		
196	Remote Start Off Load		
197	Remote Start On Load		
198	Reset Maintenance 1		
199	Reset Maintenance 2		
200	Reset Maintenance 3		
201	Scheduled Auto Start Inhibit		
202	SCR Inducement		

Continued over page...

Front Panel Configuration

Output Sources			
49	Coolant Temp Switch	126	Gen Low Volts Warning
50	Cooling Down	127	Gen High Freq Alarm
51	Data Logging Active	128	Gen High Freq Delayed Alm
52	DEF Level Low	129	Gen High Freq Delayed Warning
53	DEF Level Low Alarm	130	Gen Ph Rotation Alarm
54	Digital Input A	131	Gen Reverse Power
55	Digital Input B	132	HEST Active
56	Digital Input C	133	High Coolant Temp E Trip
57	Digital Input D	134	High Coolant Temp Sdn
58	Digital Input E	135	High Coolant Temp Warning
59	Digital Input F	136	High Inlet Temp Shutdown
60	Digital Input G	137	High Inlet Temp Warning
61	Digital Input H	138	Inhibit Scheduled Run
62	HTR Fitted and ON	139	kW Overload Alarm
63	DPF Forced Regen Requested	140	Lamp Test
64	DPF Non Mission	141	Load Freq Not Reached
65	DPF Regen Active	142	Load Volts Not Reached
66	DPF Regen Interlock	143	Loss Of MPU Signal
67	DPTC Filter	144	Louvre Control
68	Droop Enable	145	Low Coolant Temp
69	ECU (ECM) Data Fail	146	Low Load
70	ECU (ECM) Power	147	Low Oil Pressure Sdn
71	ECU (ECM) Shutdown	148	Low Oil Pressure Wng
72	ECU (ECM) Stop	149	Main Config Selected
73	ECU (ECM) Warning	150	Mains Closed Aux
74	ECU Pre-Heat	151	Mains Failure
75	EJP 1	152	Mains High Freq
76	EJP 2	153	Mains High Volts
		203	Screensaver Active
		204	Shutdown Blocked
		205	Simulate Auto Button
		206	Simulate Close Gen
		207	Simulate Lamp Test
		208	Simulate Mains Available
		209	Simulate Manual
		210	Simulate Open Gen
		211	Simulate Start
		212	Simulate Stop
		213	Simulate Test On Load
		214	Smoke Limiting
		215	Start Relay
		216	Stop And Panel Lock
		217	System In Auto Mode
		218	System In Man Mode
		219	System In Stop Mode
		220	System In Test Mode
		221	Telemetry Active
		222	Telemetry Data Active
		223	Temp Sensor OC
		224	Low Freq Alarm
		225	Low Freq Warning
		226	Low Speed Alarm
		227	Low Speed Warning
		228	Wait For Man Restore
		229	Water in Fuel