
VB-20 VB-30 PARTS LIST

No.	Part name	Code/Specification	Qty.	No.	Part name	Code/Specification	Qty.
1	nut	M20×1.5	1	64	fork	B20F-03-09	1
2	Spring washer	20	1	65	Eccentric sleeve	B20F-03-07	1
3	Flat mat	20	1	66	Cylindrical pin	φ4X20	1
4	Skeleton oil seal	SG25×52×10	1	67	Variable speed core shaft	B20F-03-03	1
5	Shaft with card spring	25	1	68	Gears with ball	φ6.5	2
6	bearing	6205	1	69	Gears with spring	B20F-03-06	2
7	Lower bearing position	B20J-01-21	1	70	Change seat	B20F-03-04	1
8	Clutch gear under	B20J-01-20	1	71	Countersunk screw	M6×15	4
9	Output shaft gear sets	B20J-01-18	2	72	Set screw	M8×10	1
10	Flat key	C6×30	2	73	Variable speed handle seat	B20F-03-02	1
11	Output shaft	B20J-01-09	1	74	Planetary gear	B20F-01-24	1
12	Flat key	A6×32	2	75	bearing	6203	1
13	Output shaft clutch	B20J-01-19	1	76	bearing	6204	1
14	Clutch on gear	B20J-01-17	1	77	Skeleton oil seal	SG25×50×10	1
15	Ratchet down flat	B20K-01-15	1	78	Flat key	C5×18	1
16	Outer ring	B20J-01-14	1	79	Taper pin	φ8X30	1
17	Roller pressure spring	B20J-01-13	4	80	Planetary shaft	B20K-01-25	1
18	roller	B20J-01-12	4	81	Centrifugal switch dynamic tablet		1
19	Star wheel within	B20J-01-11	1	82	Centrifugal switch static tablet		1
20	Ratchet bolted cover plate	B20J-01-10	1	83	Motor end cover	B20B-01-01-03	1
21	bearing	6203	2	84	Wind leaf		1
22	Flat mat	12	2	85	back cover	B20B-04-18	1
23	Spring washer	12	1	86	Half-round head screw	M5×8	4
24	nut	M12	2	87	Variable speed handle	B20F-03-01	1
25	nut	M10	2	88	hook	B20F-01-29	1
26	Spring washer	10	2	89	Beater	B20F-01-28	1
27	Flat washer	10	2	90	Whip	B20F-01-27	1
28	bearing	6201	4	91	Bowl	B20F-04-14	1
29	Middle bridge shaft	B20J-01-04	1	92	bowl spport	B20B-04-09C	1
30	Flat key	A5×14	3	93	VAT pressure handle	B20F-04-11-01	2
31	Intermediate shaft big gear	B20J-01-06	1	94	VAT positioning pin	B20J-04-22	2
32	Intermediate shaft long sleeve	B20J-01-07	1	95	Spring washer	8	2
33	Intermediate shaft pinion	B20J-01-05	1	96	nut	M8	2
34	Shaft with ring	20	2	97	post	B20B-04-06d	1
35	bearing	6201	4	98	Socket screw	M8×35	4
36	Front cover	B20F-04-04	1	99	Spring washer	8	4
37	Safely guard	B20K-05-02-02	1	100	Post HouGaiBan	B20B-04-07	1
38	Socket screw	M6×25	6	101	Outside hexagonal screw	M6×16	6
39	Inner gear ring	B20K-01-26	1	102	clamp	B10B-04-11	2
40	Half-round head screw	M5×8	4	103	base	B20B-04-08	1
41	translocation	B20F-01-23	1	104	Outside hexagonal screw	M8×45	4
42	Shield block	B20K-05-02-01	1	105	Worm shaft	B20B-02-04a-03	1
43	body	B20E-04-03	1	106	Cylindrical pin	φ4X20	1
44	bearing	B20J-04-26	1	107	worm	B20F-02-04a-01	1
45	Socket screw	M6×16	4	108	sleeve	B20B-02-04a-02	1
46	Single bearing cap	B20J-04-33	1	109	Worm seat	B20F-02-05a	1
47	Biaxial bearing cover	B20J-04-34	1	110	Countersunk screw	M5×16	2
48	Socket screw	M6×10	4	111	Socket set screw	M5×10	1
49	Half-round head screw	M5×8	5	112	Lifting the handwheel	B20F-02-03	1
50	top cover	B20K-04-01	1	113	Lifting handle	B20F-02-01	1
51	Half-round head screw	M6×35	1	114	Handle core shaft	B20F-02-02	1
52	Motor rotor	B20E-01-01-04	1	115	Outside hexagonal screw	M5×16	4
53	Flat key	A3×25	1	116	Worm wheel seat	B20F-02-06	1
54	bearing	6203	2	117	Socket screw	M5×8	1
55	Skeleton oil seal	SG17×40×8	1	118	Worm gear	B20F-02-07	1
56	Machine screw	B20J-01-01-01	1	119	Extension crank	B20F-02-08-01	1
57	Motor stator		1	120	Socket screw	M6×16	2
58	Input shaft	B20J-01-03	1	121	Connecting rod set	B20B-02-09	2
59	Worm gear	B20J-01-01-02	1	122	Connecting rod	B20B-02-08a	1
60	Fork guide	B20B-03-08	1	123	Flat washer	10	2
61	Fork with nut	B20F-03-12	2	124	Spring washer	10	2
62	Fork spring	B20F-03-11	2	125	Hexagonal screw	M10×22	1
63	Fork top pin	B20F-03-10	2	126	Hexagonal screw	M10×25	1



B20分解图