J-Type	Entrada JR rs	Salida					
		31 2	6 25	21 20		6 5	0
JR		SPECIAL 000000	rs	00000	00 0000	0000	JR 0 0 1 0 0 0
		6	5		15		6
	JALR rs (rd = 31 implied)	31 26	25 21	20 16	15 11	10 6	5 0
JALR		SPECIAL 00000	rs	00000	rd	00000	JALR 001001
		6	5	5	5	5	6
JALR							
	JALR rd, rs						