KADE-XBOX

Pin Mapping Reference Table for the Xbox Gamepad Encoder



Pin	Function	Shifted Function	Notes
A 1	Dpad Up	Analog Up	Use shift to switch between dpad and left analog stick
A2	Dpad Down	Analog Down	
А3	Dpad Left	Analog Left	
A4	Dpad Right	Analog Right	
A5	Left Trigger	Left Thumb Button	Use shift to switch between triggers and thumb buttons
A6	RightTrigger	Right Thumb Button	
A7	*Shift Status LED		Connect external LED to this pin.
A8	*Connectivity Status LED		Connect external LED to this pin
A9	*Retain Buttons in Shift Mode		Connecting a jumper wire between this pin and ground will align shift mode with analog gaming (instead of admin). The default gaming buttons will not be remapped.
A10	*Disable Start+Back		Connecting a jumper wire between this pin and ground will disable the start+back combination. The dedicated Exit Game pin is not effected.
B1	A Button		
B2	B Button		
B3	X Button		
В4	Y Button		
B5	Black	Invert Y Axis	Use shift+black to Invert Y axis on analog sticks
В6	White	Toggle Left/Right Stick	Use shift+white to toggle between controlling left and right analog sticks
B7	Start		
B8	Back		
В9	Exit Game	Exit to Dashboard	Dedicated game exit (simulates start+back) and dashboard exit (simulates LT+RT+black+back). This pin can also be held for 5 seconds to force Exit to Dashboard
B10	(Unused)		Unused
HW/B	Shift		Press to access shifted functions. Double click for shift lock
+5V	+5V Power Output		+5V power for external peripherals
RST	Reset		Restart the device
GND	Ground		Ground pin. Recommend a daisy chain ground harness is used for wiring controls.