
TR7Z-K2



NOTE 2 - AVIATION LIGHTS


1. WHEN USING SINGLE RELAY (48V) TO INDICATE GENERAL STATUS OF THE AML (VOLTAGE MONITORING ONLY, NO BUILDS COUNT) - USE EX6-1 INPUT


2. WHEN USING DC CONTROLLER OUTPUT (PER BULB), USE EX6-4. THIS WILL CAUSE THE SERVER TO 'COUNT' ACTIVE BULBS.

CONFIGURATING EX6-4 WILL CAUSE THE SERVER TO DISREGARD EX6-1 AWL INPU

- A GRID PHASE AVAILABLE WHEN VOLTAGE IS 12V
- $igorplus_{ ext{B}}$ door open when voltage is 0v
- C) SMOKE ALARM ACTIVE WHEN VOLTAGE IS 0V
- D A/C ON WHEN VOLTAGE IS 12V
- E AWL BULB IS WORKING WHEN VOLTAGE IS 12V


DEVICES LAYOUT & IDS ASSIGNMENTS





MISC DEVICES

BAUD=19200 ID=10



FUEL SENSORS



ECOM_LAYOUTS

INDOOR_ONGRID INDOOR_OFFGRID OUTDOOR_ONGRID

INDOOR_HYBRID_ONGRID INDOOR_HYBRID_OFFGRID OUTDOOR_HYBRID_ONGRID OUTDOOR_HYBRID_OFFGRID

INDOOR_SOLAR OUTDOOR_SOLAR

AWL (EX6-4)

ATC. UG. K2. REV 1.07

Titles are update up tritaling trital derions layout vectors

Title ATC LOS TRIZ Wring

Bin Document Names

Tought developed

Tought for developed

Tought for the tritaling tri