LIbraries to install

DHT(Adafruit)



• ESP8266 library(first add

https://arduino.esp8266.com/stable/package_esp8266com_index.json file preferences > additional boards manager URLs . Go back to Tools > Board > Go to boards manager > search for ESP8266 board > install > select Generic ESP8266 Module)

Connecting ground and vcc

Ground: - part of breadboard

Vcc - varies basing on the different elements but it originates from the ESP8266 board

Vcc of DHT11: 3v3 Vcc of LCD:5v

Connecting the dht11 sensor

S pin:D5;

Middle Pin :Vcc :3v3 on ESP8266 board; Negative Pin : Ground on the board

Connecting the LCD

SCL pin:D1 SDA pin:D2 Vcc pin:5V GND pin:Gnd

Buzzer

S:D6

Middle Pin:5v

Negative pin : Ground

LEDs

- -Put resistors on the negative pin and connect to ground
- -Connect the Red pin on the d4 of esp8266 board;
- -Connect the Green pin on the d7 pin of the esp8266 board;