

A330 MCDU Preflight (PF), page flow

FCOM R17 (15 MAY 26) PRO-NOR-SOP-04, SOP-06. Pre-initialization is CM1 (SOP-04), the FMGES preparation is PF, the crosscheck is PM, the Departure Legs Verification is both (SOP-06). Numbers in brackets are MCDU line-select keys.

Before: ATIS (CM2 obtains). RUNWAY IN USE, ALTIMETER SETTING, WEATHER DATA (SOP-04).

1 - FMGS Pre-Initialization (CM1, SOP-04)

1. **DATA CM1** MCDU ON (short press BRT); no amber annunciator lights; wait out the 3 min FMGS/FCU power-up tests. A/C STATUS [4L]: model A330-200 or A330-300, ENG type TRENT772B-60. ACTIVE NAV DATABASE: cycle the Second NAV Database [3L] twice to erase pilot and uplinked data, DELETE ALL [5R] if STORED shows anything. FMS DATABASE VALIDITY: day, month, year (HAL8YYMMNN). NAVAID DESELECTION as required: DATA, POSITION MONITOR [1L], SEL NAVAIDS [6R], DESELECT [1R].
2. **INIT A (PART 1) CM1** INIT key. Enter the flight number in FLT NBR [3L] exactly as it appears on the ATC Flight Plan section of the dispatch release (e.g. HAL25), then INIT REQUEST* [2R]. Do not enter TO/FROM [1R] or the INIT REQUEST* prompt will not appear; a wrong TO/FROM is cleared by cycling the NAV database.

2 - INIT A, Part 2 (PF, SOP-06)

3. **INIT A (PART 2) PF** first IDLE / PERF FACTOR check. INIT key. TO/FROM [1R] confirms the uplink; wrong means cycle the NAV database. ALTN [2L] enter from the release. FLT NBR [3L], COST INDEX [5L], CRZ FL/TEMP [6L] check against the release. TROPO [5R] optional, improves predictions.
4. **WIND PF** WIND [5R], NEXT PHASE / PREVIOUS PHASE through CLIMB, CRUISE, DESCENT. Verify the automatic wind uplink came with the flight plan. If NO ANSWER TO REQUEST: WIND REQUEST* [2R], or enter the release winds by hand (cruise: initial CRZ waypoint, then waypoints with a 30 kt, 30 deg or 5 deg SAT change or a step). To get an altitude that did not uplink, enter 0/0/350 and send again.

3 - F-PLN, SEC F-PLN, RAD NAV (PF, SOP-06)

5. **F-PLN DEPARTURE PF** FPLN key. LAT REV at the departure airport [1L], DEPARTURE [1L], select the RWY, the SID and SID transition; verify RWY [1L], SID and transition [1R] on the top row; TMPY INSERT* [6L]. To change the RWY with a SID already in, slew back to departure page 1.
6. **F-PLN ENROUTE and ARRIVAL PF** check ENROUTE WAYPOINTS and AIRWAYS; enter STEP ALTS. LAT REV at the arrival airport [6L], ARRIVAL [1R], select the APPR, the STAR and STAR transition; verify APPR [1L], APPR VIA [2L], STAR [1R], STAR transition [2R]; TMPY INSERT* [6L].
7. **ETOPS PF** DATA, right arrow to DATA INDEX page 2, STORED WAYPOINTS [1R], name ETP1 etc., enter LAT/LONG from the flight plan, STORE [6R]. Do not enter the ETPs as waypoints in the flight plan. FIX INFO: F-PLN, LAT REV at the FROM waypoint [1L], FIX INFO [1R], REF FIX [1L] = the stored ETP (max 4 FIX INFO waypoints). EQUITIME POINT: DATA, EQUITIME POINT, ETOPS alternates in [1L] and [3L] with TRU WIND [2L] and [4L] at CRZ FL.
8. **SEC F-PLN PF** routinely a copy of the active flight plan, but consider: copy and modify at a suitable waypoint for an immediate return (engine failure); if departure weather is below landing minima, the diversion right after takeoff; if a runway or SID change during taxi is likely, copy and pre-modify.
9. **RAD NAV PF** check the VOR, ILS and ADF tuned by the FMGC; modify if required and check the correct identifier is displayed on the ND and PFD (VOR, ILS). If unsatisfactory, go through the audio check.

4 - INIT B, INIT FUEL PRED (PF, SOP-06)

10. **INIT B PF** INIT then horizontal slew (labeled INIT FUEL PRED on some FMGS). TAXI [1L] adjust only for a large disparity. RTE RSV / % [3L] = 0 so EXTRA shows the fuel you actually manage (the dispatcher carries route reserve as 10 PCT TIME). ALTN/TIME [4L]: if the release ALTN fuel differs from the FMS value, enter the greater; pilot entries overwrite the FMS and must be cleared or redone when the alternate, routing or altitude changes. FINAL/TIME [5L]: Final Reserve per FOM fuel policy, 30 min holding at 1 500 ft AFL, protected. ZFW/ZFWCG [1R] from the release if not auto-populated, ZFWCG may stay blank. BLOCK [2R]: FOB from the EWD once fueled, else Ramp Fuel from the release. EXTRA/TIME [6R] check. INIT B is not available after engine start.

5 - PERF and PROG (PF, SOP-06)

11. **PERF TAKE OFF PF** PERF key. SHIFT: insert a T.O shift for an intersection takeoff even with GPS PRIMARY. THR RED/ACC and ENG OUT ACC: set or check, default 1 000 ft above departure runway altitude, modify for the expected RWY/SID. A takeoff data uplink deletes previously entered THR RED / ACCEL ALT (SOP-07 Takeoff Data). TPR/TLR data goes in later, before pushback.
12. **PERF CLB, CRZ, DES PF** NEXT PHASE [6R] through the pages. CLB and CRZ PRESEL speed as required (green dot for a close-in turn or constraint, a CRZ Mach; cancel with ECON before the phase activates). DRT CLB as required: D1 for TOW below 463 000 lb, D2 below 441 000 lb. DES: descent Mach equals end-of-cruise Mach, edit the crossover speed [3L] to 300 kt, or the published STAR transition speed (HAWKZ4 into SEA is 280 kt). SPD LIM 250 kt below 10 000 ft is cleared or changed on the VERT REV page.
13. **PROG PF** BRG / DIST TO as appropriate: the runway ident for an immediate return, the destination, or an ETP. RNP: for an RNP AR departure, check or insert the RNP.

6 - Crosscheck (PM, SOP-06)

14. **FMS PREPARATION CROSSCHECK PM** after the PF prepares the FMS the PM checks everything entered: departure waypoints with constraints; flight plan waypoints vs the computerized flight plan; initial cruise altitude; total track miles; fuel remaining at destination; performance data including THR RED/ACCEL/EO ACCEL changes; TRANS ALT on the ACTIVE/PERF page; SEC flight plan setup. The PM must hold the same mental picture of the departure as the PF and asks if anything is unclear (FCTM PR-NP-SOP-60).

After: DEPARTURE LEGS VERIFICATION (BOTH). PF reads the ND (PLAN, CSTR), PM verifies the paper · F-PLN DIST and EFOB vs release (SOP-06), then the Departure Briefing and the COCKPIT PREPARATION C/L.