

B787 QRH Memory Items // Recite Cold

Source: Hawaiian Airlines QRH Rev 7 (19 Jan 2026). Recall items only - the steps above the dashed line, recited cold. Ten checklists carry memory items.

CABIN ALTITUDE QRH 2.1 <i>Condition: Cabin altitude is excessive.</i> 1 Don the oxygen masks. 2 Establish crew communications. 3 Check the cabin altitude and rate. 4 If the cabin altitude is uncontrollable: PASS OXYGEN switch: Push to ON and hold for 1 second Without delay, descend to the lowest safe altitude or 10,000 feet, whichever is higher. To descend: • Move the thrust levers to idle • Extend the speedbrakes • If structural integrity is in doubt, limit airspeed and avoid high maneuvering loads • Descend at Vmo/Mmo	FIRE ENG L, R QRH 8.2 <i>Condition: Fire is detected in the affected engine.</i> 1 Choose one: • On the ground: Go to step 13 • In flight: Go to step 2 2 A/T ARM switch (affected side): Confirm OFF 3 Thrust lever (affected side): Confirm Idle 4 FUEL CONTROL switch (affected side): Confirm CUTOFF 5 Engine fire switch (affected side): Confirm Pull 6 If the FIRE ENG message stays shown: Engine fire switch (affected side): Rotate to the stop and hold for 1 second
ABORTED ENGINE START L, R QRH 7.1 <i>Condition: On the ground, an aborted engine start is needed.</i> 1 FUEL CONTROL switch (affected side): CUTOFF	STABILIZER QRH 9.1 <i>Condition: Stabilizer movement without a signal to trim, or the stabilizer is failed.</i> 1 STAB cutout switches (both): CUTOUT 2 Do not exceed the current airspeed.
DUAL ENG FAIL/STALL QRH 7.2 <i>Condition: Engine speed for both engines is below idle.</i> 1 FUEL CONTROL switches (both): CUTOFF, then RUN 2 RAM AIR TURBINE switch: Push and hold for 1 second	AIRSPEED UNRELIABLE QRH 10.1 <i>Condition: The airspeed or Mach indications disagree with AOA calculated airspeed.</i> 1 Autopilot disconnect switch: Push 2 A/T ARM switches (both): OFF 3 F/D switches (both): OFF 4 Set the following gear up pitch attitude and thrust: • Flaps extended: 10 deg and 85% N1 • Flaps up: 4 deg and 70% N1
ENG AUTOSTART L, R QRH 7.3 <i>Condition: Autostart did not start the engine.</i> 1 FUEL CONTROL switch (affected side): Confirm CUTOFF	
ENG LIMIT EXCEED L, R QRH 7.4 <i>Condition: An engine limit exceedance occurs.</i> 1 A/T ARM switch (affected side): Confirm OFF 2 Thrust lever (affected side): Confirm Retard until ENG LIMIT EXCEED message blanks or the thrust lever is at idle	
ENG SURGE L, R QRH 7.7 <i>Condition: An engine surge or stall that requires crew action is detected.</i> 1 A/T ARM switch (affected side): Confirm OFF 2 Thrust lever (affected side): Confirm Retard until the ENG SURGE message blanks or the thrust lever is at idle	
ENG SVR DAMAGE/SEP L, R QRH 7.10 <i>Condition: Airframe vibrations with abnormal engine indications, or engine separation.</i> 1 A/T ARM switch (affected side): Confirm OFF 2 Thrust lever (affected side): Confirm Idle 3 FUEL CONTROL switch (affected side): Confirm CUTOFF 4 Engine fire switch (affected side): Confirm Pull	