8:16 USER'S GUIDE

Volume 1

8:16 Operator's Guide (MS-DOS)

MS-DOS Guide (MS-DOS)



How to USE this Guide

Attache 8:16 documentation consists of "user's guides" packaged in two separate books called Volume 1 and Volume 2. Generally, manuals in Volume 1 apply to MS-DOS and manuals in Volume 2 apply to CP/M. The exceptions are the Valet Guide and Software Guide, which apply for either operating system.

The contents of User's Guide Volumes 1 and 2 are as follows:

Volume 1

8:16 Operator's Guide (MS-DOS)

MS-DOS Guide (MS-DOS)

Volume 2

Operator's Guide (CP/M)

Valet Guide (MS-DOS and CP/M)

Software Guide (MS-DOS and CP/M)

Charton Guide (CP/M)

CP/M Guide (CP/M)

The general contents of these manuals are described on the following pages. Use these pages as a master reference guide to the entire manual set. Note that each user's guide contains its own comprehensive glossary and index for easy reference.

Other Attache 8:16 publications not described here include:

- o Attache Technical Manual and 8:16 Supplement
- Attache Service Guide and 8:16 Supplement
- o Attache GPIB/Multifunction Technical Manual
- o MS-DOS Programmer's Guide (with Macroassembler)
- o Attache CP/M and MS-DOS BIOS Listings
- o Attache WordStar-Plus and Multiplan Manuals

The Technical Manual, GPIB/Multifunction Technical Manual, MS-DOS Programmer's Guide, and BIOS Listings may be purchased from your dealer. The Service Guide is sent to you free by Otrona when you return your Owner's Warranty and Registration cards. The WordStar-Plus and Multiplan manuals are included with purchase of those software systems.

8:16 Operator's Guide (MS-DOS)

The 8:16 Operator's Guide contains instructions for setting up and operating Attache 8:16 with MS-DOS.

Chapter 1 - Introduction Basic computer concepts

8086 and Z80A dual processors MS-DOS and CP/M compatibility 8:16 and IBM-PC compatibility Attache 8:16 components Power cords and voltages Fuses and clock batteries

Chapter 2 - Getting Started Setting up the unit

Turning on the power Inserting diskettes Booting MS-DOS

Turning the system off Using the dual processors

Changing diskettes

Displaying the file directory File naming conventions

Chapter 3 - Diskettes Diskettes to use

Diskette handling procedures Formatting blank diskettes MS-DOS and CP/M formats Making duplicate diskettes Using IBM-PC software diskettes 96 TPI diskette drive option

Chapter 4 - Keyboard Typewriter and modifier keys

Multi-function keys

10-key Mode and Set-Up Mode WordStar Mode and IBM-PC Mode

Keyboard templates

Chapter 5 - Ports Attache's serial ports

Cable connection
Baud rate selection

Cable wiring specifications

IBM-PC compatibility

Chapter 6 - Programmer Reference Accessing the display driver

Color monitor compatibility Cursor and erase functions Keyboard reassignment ASCII Mode and IBM-PC Mode IBM-PC Codes and Conversion Accessing the sound generator

MS-DOS interrupts

Appendixes Technical specifications

MS-DOS Guide

The MS-DOS Guide contains information about the MS-DOS operating system and detailed instructions for using DOS utility programs.

Chapter 1 - Introduction Operating system overview

Commands and functions summary Syntax notation and DOS files

Chapter 2 - Getting Started Booting MS-DOS

Format and copy diskettes Files and the file directory

Chapter 3 - Files Filenames

Wild cards

Directories and subdirectories

Paths

Chapter 4 - More about Commands Command options

Batch processing

Automatic program execution

Redirecting output Filters and command piping

Chapter 5 - DOS Commands

DOS command summary Individual DOS commands

Chapter 6 - Function Keys

Editing keys

Control character functions

Chapter 7 - EDLIN

Line editor overview Special editing keys

EDLIN commands

Chapter 8 - File Comparison

File Compare (FC) command

Command options

FC reporting and examples

Chapter 9 - Configuration

Changing CONFIG.SYS Device drivers and headers

Strategy and interrupt routines

Function call parameters

Appendixes

ANSI escape sequences

Single drive systems

Disk errors

MS-DOS technical information Control blocks and work areas MS-DOS command reference tables

Function request summary

Attache Operator's Guide (CP/M)

The Attache Operator's Guide contains instructions for setting up and operating Attache 8:16 with CP/M.

Chapter 1 - Introduction Basic computer concepts

Attache components Power cords and voltages Fuses and clock batteries Maintenance requirements

Chapter 2 - Getting Started Setting up the unit

Turning on the power Inserting diskettes Booting CP/M Changing diskettes

Changing the logged drive

Chapter 3 - Diskettes Diskettes to use

Diskette handling procedures Formatting blank diskettes Software installation File naming conventions CP/M disk error messages

Chapter 4 - Keyboard Typewriter and modifier keys

Multi-function commands

Set-Up Mode

10-key emulation keys

Chapter 5 - Ports Attache's serial ports

Cable connection
Baud rate selection

Cable wiring specifications

Pin connections

Chapter 6 - Programmer Reference CMOS RAM locations

Escape codes

Screen attributes Character sets

ASCII codes Terminal emulation

SIO initialization I/O port locations Clock and synthesizer

Appendixes Technical specifications

Software Guide

The Software Guide contains instructions for using Attache utility programs for CP/M and the Disk Manager program with CP/M or MS-DOS.

Chapter 1 - Introduction

Attache software programs Attache program files

Chapter 2 - Utility Programs

Set the clock Change port protocol Automatic program load Re-execute last program List directory and file size

Chapter 3 - Disk Manager

Copy an entire diskette Format a diskette

Copy CP/M
Copy a file
Rename a file
Delete a file
View a file
Print a file

Appendixes

CP/M Guide

The CP/M Guide contains information about the CP/M operating system and detailed instructions for using CP/M utility programs.

Chapter 1 - Introduction Basic computer concepts

Command mode

Filenames and file types Wild card matching characters

Chapter 2 - Basic Commands DIR - Directory display

ERA - Erase a file REN - Rename a file

TYPE - Type a file STAT - System status display

PIP - Copy a file

SUBMIT - Execute batch commands XSUB - Insert SUBMIT variables

Chapter 3 - Device Assignment

STAT device options PIP device options

USER options

Chapter 4 - Program Development

Memory organization ASM - Assembler

DDT - Dynamic Debugging Tool

Ed - Text Editor

Chapter 5 - Error Messages

CP/M error messages Recovery options

Appendixes

Command summary reference

Valet Guide

The Valet Guide contains detailed instructions for using the Valet time/resource management system.

Chapter 1 - Introduction Set-up and Main Menu functions

Valet files

Chapter 2 - Set-Up Mode Display time and date

Vary screen brightness Vary keyboard volume
Vary keyboard sound
Vary printer port baud rate
Vary comm port baud rate

Set the clock

Alarm types Chapter 3 - Alarms

Messages Commands Setting alarms Answering alarms Cancelling alarms

Chapter 4 - Screen Dump Screen dump options

Activating screen dump

Chapter 5 - Printer Installation Installing Printers

Printer settings

Activating the calculator Number and function keys Chapter 6 - Calculator

Memory registers Storage registers Scientific notation Calculator examples

Appendi xes Glossary and index

Charton Guide

The Charton Guide contains detailed instructions for learning and using the Charton business graphics system, including bar charts, line charts, and pie charts.

Chapter 1 - Introduction

Charton functions Charton files Activating Charton Charton Main menu Create new charts Display existing charts

Chapter 2 - Bar Charts

Create new bar charts Save bar charts Print bar charts

Display existing bar charts

Revise bar charts

Chapter 3 - Line Charts

Create new line charts Save line charts Print line charts

Display existing line charts

Revise line charts

Chapter 4 - Pie Charts

Create new pie charts Save pie charts Print pie charts

Display existing pie charts Revise pie charts

Appendixes