

TechMart Electronics - General User Manual & Safety Guide

Electrical Safety Guidelines:

To prevent shocks or fires, do not expose TechMart devices to high moisture, water spills, or direct heat elements. Use only the factory-supplied wall charging adapters.

Factory Reset Procedures:

To restore default settings, locate the reset button pinhole. Using a paperclip, press and hold the button for 10 seconds until the status indicator flashes amber.

Troubleshooting Support Contact:

For hardware diagnostics, spare parts queries, or device guide assistance, email support@techmart.com to speak with a technical support representative.