Savitech DSD64 and DSD128 playback on foobar2000

Description

For DSD64 and DSD128 playback on foobar2000, please refer to this AP-Note to set your system environment


Before these steps, please install foobar2000.

Please download these application plug-ins,


- 1. ASIOProxyInstall-0.8.3
- 2. foo-input-sacd.fb2k-component
- 3. foo_out_asio_v2p1p2.fb2k-component

Step 1


Double click this file to install component ASIO support (foo_out_asio_2.1.2 for foobar player)




Step 2 Click button yes(Y) to continue




Click button OK on Preference: Components and then click button OK on foobar2000 preferences to apply the change







Click this file ASIOProxyInstall-0.8.3.exe and then approve this installation,
Click button NEXT and then click button Install to install ASIO Proxy for foobar2000




<u>Step 5</u> Open foobar2000 preferences




Change ASIO Driver Mode: DSD (from Tools -> SACD)




Click button Add New to add ASIO channel mapping (from Playback -> Output -> ASIO)






Select ASIO driver: "BRAVO-HD," select DSD playback Method: "dop marker ox05/0xFA"




Select Device: ASIO: foo_dsd_asio-my channel mapping (from Playback -> Output)




Step 9

Finish all setting



Step 10

When DSD64 playback, foobar shows playback status as below



The Bravo-HD ACPL shows ASIO information as below



When DSD128 playback, foobar shows playback status as below



The Bravo-HD ACPL shows ASIO information as below

