
FIXING EVERYDAY DEVICE PROBLEMS

Fast diagnostics and fixes for keyboards, audio, webcams, and printers

HARDWARE TRIAGE | WINDOWS & APPS | NO JARGON

A quick reference guide for home and office workstations



Made with GAMMA

FIVE USB KEYBOARD AND MOUSE ISSUES, FIVE FIXES

Device not recognized: Try another USB port, then reinstall the driver in Device Manager.

Laggy or skipping mouse: Clean the sensor, change surface, move the dongle closer or use a wired port.

Keys type wrong characters: Check the keyboard language and layout in Windows settings.

Works then disconnects: Turn off USB selective suspend in Power Options.

Touchpad conflicts or ghost clicks: Disable the touchpad when a mouse is connected.



BLUETOOTH HEADPHONES WON'T CONNECT: STEP-BY-STEP FLOW

1. Check headphone battery and LED indicator; charge if blinking red or off.
2. Confirm phone Bluetooth is on in Settings and Airplane mode is off.
3. Put headphones in pairing mode: hold power until the LED flashes blue and white.
4. Remove the old pairing: tap the gear next to the headphones, then Forget this device.
5. Rescan, select the headphones, and accept the pairing prompt.
6. Still failing: toggle Bluetooth, restart the phone, and reset the headphones per the manual.
7. Last resort: reset network settings and test with another phone to isolate the fault.



WEBCAM NOT DETECTED IN ZOOM: A SIX-POINT CHECKLIST

1. Reseat the cable and try a different USB port, avoiding hubs.
2. Open Device Manager; check Cameras or Imaging devices for warnings, then update or reinstall the driver.
3. In Settings, Privacy, Camera, turn on camera access and allow desktop apps.
4. In Zoom settings, Video, select the external webcam from the Camera dropdown.
5. Close other apps that may hold the camera, such as Teams or a browser.
6. Restart the PC and test in the Windows Camera app to confirm the hardware works.



PRINTER SHOWS OFFLINE: USING THE WINDOWS TROUBLESHOOTER

1. Open Settings, Update and Security, Troubleshoot, Additional troubleshooters, then run Printer.
2. Select the offline printer and let the scan run.
3. The tool checks print spooler service status, printer connection and network reachability, driver status, and default printer setting.
4. Review findings such as "Printer is offline" or "Spooler restarted", then apply the suggested fix.
5. Re-test with a print job. If still offline, check cables or Wi-Fi and clear the print queue.



QUICK RECAP: CHECK BASICS FIRST, THEN DRIVERS AND SETTINGS

A disciplined three-tier diagnostic sequence prevents unnecessary reinstalls and hardware swaps.

TIER 01 · PHYSICAL

BASICS

Reseat cables, swap USB ports directly to the motherboard, check battery charge, and reboot host devices.

FIXES 60% OF ISSUES

TIER 02 · SYSTEM

DRIVERS

Verify Device Manager flags, toggle camera and mic privacy toggles, and forget stale Bluetooth pairings.

PERMISSIONS & STATE

TIER 03 · AUTOMATED

TOOLS

Run Windows built-in troubleshooters to restart services and reset stuck print queues before reinstalling.

BUILT-IN RECOVERY

Remember: Reseat, restart, check permissions, and run native tools before replacing hardware.

Made with GAMMA