



Operating manual

sks-15/CF

Ultrasonic proximity switch with one switching output and IO-Link interface

Product description

The sks sensor offers a non-contactmeasurement of the distance to an object which must be positioned within the sensor's detection zone. The switched output is set in dependance of the adjusted detect distance.

Via the push-button, the distance and operating mode can be adjusted (Teach-in). Two LEDs indicate operation and the state of the switched output. The output function is changeable from NOC to NCC.

The sks-15/CF sensor is IO-Link capable in accordance with IO-Link specification V1.1.

Safety notes

- Read operating instructions pior to start-up.
- Connection, installation and adjustment works may only be car-

ried out by expert personnel

No safety component according to
EU Machinery Directive

Proper use

sks ultrasonic sensors are used for non-contact detection of objects.

Mounting

- Mount the sensor at installation site, Maximum torque: 0.5 Nm
- Connect a connection cable to the M8 device plug

Start-Up

- Connect the power supply
- Carry out the adjustment in according with the diagram

Factory setting

- Operating with one detect point
- Switched output on NOC
- Detect points at operating range

20 04 0 0 1 3 colour 1 +U_B brown 3 -U_B blue 4 F black 2 Com white

Fig. 1: Pin assignment with view of the sensor plug and color coding of the microsonic connection cables

- Filter F01
- Filter strength P00

Operating modes

Three operating modes are available for the switches output:

- Operation with one switching point The switched output is set if the object falls below the set detect point.
- Window mode

The switched output is set if the object is outside the set window margins.

Two-way reflective barrier
 The switched output is set if the object is located between the sensor and reflector.

Checking operation mode

 In normal mode shortly press the push-button.

The green LED stops shining for one second, then it will show the current operating mode:

- 1 x flashing = operation with one switching point
- 2 x flashing = window mode
- 3 x flashing = reflective barrier

After a break of three seconds, the green LED shows the **output function**:

- 1 x flashing = NOC
- 2 x flashing = NCC

Maintenance

microsonic sensors are maintenancefree. In case of excess caked-on dirt we recommend cleaning the white sensor surface.

WICLO\OUIC

Notes

- Every time the power supply is switched on, the sensor detects its actual operating temperature and transmits it to the internal temperature compensation. The adjusted value is taken over after 45 seconds.
- If the sensor was switched off for at least 30 minutes and after power on the the switched output is not set for 30 minutes a new adjustment of the internal temperature compensation to the actual mounting conditions takes place.
- The sks sensor has a blind zone whithin which distance measurements are not possible.
- In the normal operating mode, an illuminated yellow LED signals the switched output is switched through.
- In the »Set detect point method A« Teach-in procedure the actual distance to the object is taught to the sensor as the detect point. If the object moves towards the sensor (e.g. with level control) then the taught distance is the level at which the sensor has to switch the output.
- If the object to be scanned moves into the detection area from the side, the »Set detect point +8 % – method B« Teach-in procedure should be used. In this way the switching distance is set 8 % further than the actual measured distance to the object. This ensures a reliable switching distance even if the height of the objects varies slightly, see fig. 2.
- In the »Two-way reflective barrier« operating mode, the object has to be within the range of 0-85 % of the set distance.
- If the push-button is not pressed for 10 minutes during the teach-insetting, the settings made hitherto are deleted.
- The sensor can be reset to its factory setting.


Contact


Sensor Partners BV

- James Wattlaan 155151 DP DrunenThe Netherlands
- \$\&\ +31 (0)416 37 82 39
- sensorpartners.com

Sensor Partners BVBA

- Z.1 Researchpark 310B-1731, ZellikBelgium
- +32 (0)2 464 96 90
- sensorpartners.com





Sensor adjustment in IO-Link mode

The sks sensor is IO-Link-capable in accordance with IO-Link specification V1.1.

Pointer

- In IO-Link mode Teach-in vis pushbutton is not available.
- For current information about IO-Link please contact the microsonic sales department.

Synchronisation in IO-Link mode

In IO-Link mode each sensor is synchronized on the protocol of the IO-Link master.

In multiple sensor operation the sensors are synchronous if the master protocols are synchronous.

Process data

The sks cyclically transmits the measured distance value with a resolution of 0.1 mm and the logical state of the switched output.

Service data

The following sensor parameters may be set via IO-Link interface using the IO-Link device description (IODD).

Detect point 1

The switched output is activated when the distance to an object is smaller than the present detect point.

Return detect point 1

The switched output is reactivated

when the distance to an object is greater than the present return detect point (detect point + hysteresis).

Pointer

The return detect point 1 must always be greater than the detect point 1.

Detect point 2, return detect point 2

By programming these two detect distances to a value smaller than the actual maximum distance the window mode is activated. The window lies between detect point 1 and detect point 2.

Pointer

The return detect point 2 must always be smaller than the detect point 2.

Set NOC/NCC

The NCC or NOC output function can be present for the switched output.

Measurement filter

sks ultrasonic sensors provide for a choice of five filter settings:

- F00 (no filter)
 Each ultrasonic measurement acts in an unfiltered manner on the output.
- F01 (standard filter)
 On the object continuously approaching the sensor, the ongoing

interval is immediately taken on and the output correspondingly activated. The effect of the object abruptly moving away from the sensor is for the existing distance to be saved for a retaining time dependent on the filter strength and for the switched output state to be maintained.

- FO2 (Average value filter)
 Forms the arithmetic mean across
 a number of measurements. The
 output is activated in keeping with
 the average value. The number of
 measurements, from which the
 average value is formed, depends
 on the selected filter strength.
- F03 (foreground filter)

This filter reacts very fast on sensor close measurement values and gives a straightened output on this sensor close level. Disturbances from objects in the background or momentary loss of echoes from the object to be detected are filtered out.

■ F04 (background filter)

This filter reacts very fast on sensor far measurement values and gives a straightened output on this sensor far level. Disturbances from obstacles in front of the object to be detected are filtered out.

Filter strength

A filter strength between 0 – weak filter effect – and 9 – pronounced filter effect – can be selected for each.

Teach-in via push-button

The push-buttons can be locked/unlocked for the Teach-in procedures in SIO mode.

Temperature compensation

The temperature compensation improves the measurement accuracy at changing ambient temperature and may be deactivated.

Pointer

The measurement accuracy amounts to 0.17 %/K change of temperature without compensation.

System commands

With five system commands the following settings may be carried out:

- Teach-in detect point.
- Teach-in detect point +8 %.
- Teach-in window mode detect point 1
- Teach-in window mode detect point 2
- Teach-in two way refective barrier.

Pointer

To achieve the minimum response time the Master Cycle Time has to comply with the following requirements:

- Min Cycle Time ≤ Master Cycle Time ≤ Min Cycle Time + 1.2 ms.
- If this condition can not be full-filled, the sensor will adapt its internal measurement cycle to the actual Master Cycle Time. This will have influence on the response time and the behaviour of the measurement filter.
- If an invalid Master Cycle Time is set, the sensor will send an event and will stop the ultrasonic measurement.

IODD file

The latest IODD file you will find on the internet under www.microsonic.de/en/IODD.

For further informations on IO-Link see www.io-link.com.