





Operating manual crm+ Ultrasonic Sensors with one switching output and IO-Link

crm+25/F/TC/E crm+35/F/TC/F crm+130/F/TC/E crm+340/F/TC/E

crm+600/F/TC/F

● IO-l ink

Product description

- The crm+ sensor offers a non-contact measurement of the distance to an object which must be positioned within the sensor's detection zone.
- The ultrasonic transducer surface of the crm+ sensors is laminated with a PEEK film. The transducer itself is sealed against the housing by a PTFE joint ring. This composition ensures a high resitance against many aggressive substances.
- All settings are done with two push-buttons and a three-digit LED-display (TouchControl).
- Two LEDs indicate opration and the state of the switching output.
- The output functions are changeable from NOC to NCC.
- The sensors are adjustable manually using the numerical LED-display or may be trained via Teach-in procedure.
- Useful additional functions are set in the
- Using the LinkControl adapter (optional accessory) all TouchControl and additional sensor parameter settings may be made by a Windows software.
- The crm+ sensors are IO-Link capable according to specification V1.1 and support

Smart Sensor Profile like Digital Measuring Sensor.

Safety Notes

- Read the operating manual prior to start-
- Connection, installation and adjustment works may only be carried out by quali-
- No safety component in accordance with the EU Machine Directive

Use for intended purpose only

crm+ ultrasonic sensors are used for noncontact detection of objects.

The crm+ sensors indicate a blind zone, in which the distance cannot be measured. The operating range indicates the distance of the sensor that can be applied with normal reflectors with sufficient function reserve. When using good reflectors, such as a calm water surface, the sensor can also be used up to its maximum range. Objects that strongly absorb (e.g. plastic foam) or diffusely reflect sound (e.g. pebble stones) can also reduce the defined operating range.

Synchronisation

If the assembly distances shown in Fig.1 for two or more sensors are exceeded the integrated synchronisation should be used. Connect Sync/Com-channels (pin 5 at the units receptable) of all sensors (10 maximum).

	Ļ	
	$\dot{\Box}$	D⊸a
D	≥0.35 m	≥2.50 m
	≥0.40 m	≥2.50 m
D.001111	≥1.10 m	≥8.00 m
D	≥2.00 m	≥18.00 m
D(((((()))	≥4.00 m	≥30.00 m
	,	'

Fig. 1: Assembly distances, indicating synchronisation/multiplex

Multiplex mode

The Add-on-menu allows to assign an individual address »01« to »10« to each sensor connected via the Sync/Com-channel (Pin5). The sensors perform the ultrasonic measurement sequentially from low to high address. Therefore any influence between the sensors is rejected.

The address »00« is reserved to synchronisation mode and deactivates the multiplex

mode. (To use synchronised mode all sensors must be set to address »00«)

Assembly instructions

- Mount the sensor at the installation loca-
- Connect a connection cable to the M12 device plug, see fig. 2.




Fig. 2: Pin assignment with view onto sensor plug and colour coding of the microsonic connection cable


Factory setting

crm+ sensors are delivered factory made with the following settings:

- Switching output on NOC
- Switching point at operating range

■ Measurement range set to maximum ran-

Set the parameters of the sensor manually or use the Teach-in procedure to adjust the detect points.



Fia. 3: TouchControl

Maintenance

crm+ sensors are maintenance-free. In case of excess caked-on dirt we recommend cleaning the sensor surface

Note

- As a result of the design the assembly of PEEK film and PTFE joint ring is not gasproof.
- The chemical resistance has to be tested experimentally if necessary.
- crm+ sensors have internal temperature compensation. Because the sensors heat up on their own, the temperature compensation reaches its optimum working point after approx. 30 minutes of operati-
- During normal operating mode, a yellow LED D2 signals that the switching output is set.
- During normal operating mode, the measured distance value is displayed on the LED-display in mm (up to 999 mm) or cm (from 100 cm). Scale switches automatically and is indicated by a point on top of the digits.
- During Teach-in mode, the hysteresis value is set back to factory settings.
- If no objects are placed within the detection zone the LED-display shows »- - -«.
- If no push-buttons are pressed for 20 seconds during parameter setting mode, the parameter changes are saved and the sensor returns to normal operating mode.
- You can reset the factory settings at any time, see »Key lock and factory setting«.
- The latest IODD file and informations about start-up and configuration of mic+ sensors with IO-Link, you will find online at: www.microsonic.de/crm+.

Show parameters

Tapping push-button T1 shortly during normal operating mode shows »PAr« on the LED-display. Each time you tap push-button T1 the actual settings of the switching output are displayed







Contact

Sensor Partners BV

- James Wattlaan 15 5151 DP Drunen The Netherlands
- +31 (0)416 37 82 39
- info@sensorpartners.com
- sensorpartners.com

Sensor Partners BVBA

- Z.1 Researchpark 310 B-1731, Zellik Belgium
- +32 (0)2 464 96 90
- info@sensorpartners.com
- sensorpartners.com

