



Operating Manual

mic+ Ultrasonic Sensors with one analogue output

mic+25/IU/TC mic+35/IU/TC mic+130/IU/TC mic+340/IU/TC mic+600/IU/TC

Product description

- The mic+ sensor with one analogue output measures the distance to an object within the detection zone contactless. A signal proportional to distance is created according to the adjusted window limits of the analoque characteristic curve.
- The sensor automatically detects the load put to the analogue output and switches to current output or voltage output respectively.
- All settings are done with two pushbuttons and a three-digit LED display (TouchControl).
- Three-colour LEDs indicate all operation conditions.
- Choosing between rising and falling output characteristic is possible.
- The sensors are adjustable manually via TouchControl or via Teach-in procedure.

- Useful additional functions are set in the Add-on menu.
- Using the LinkControl adapter (optional accessory) and the LinkControl software for Windows®, all Teach-in and additional sensor parameter settings can be optionally undertaken.

The mic+ sensors have a blind zone in which distance measurement is not possible. The operating range indicates the distance of the sensor that can be applied with normal reflectors with sufficient function reserve. When using good reflectors, such as a calm water surface, the sensor can also be used up to its maximum range. Objects that strongly absorb (e.g. plastic foam) or diffusely reflect sound (e.g. pebble stones) can also reduce the defined operating range.

Safety Notes

- Read the operating instructions prior to start-up.
- Connection, installation and adjustment works may only be carried out by expert personnel.
- No safety component in accordance with the EU Machine Directive, use in the area of personal and machine protection not permitted

Proper Use

mic+ ultrasonic sensors are used for non-contact detection of objects.

Synchronisation

If the assembly distances shown in Fig. 1 for two or more sensors are exceeded the integrated synchronisation should be used. Connect Sync/Comchannels (pin 5 at the units receptable) of all sensors (10 maximum).

占

≥0.35 m

≥0.40 m

≥1.10 m

≥2.00 m

nisation/multiplex

 $\square \neg \square$

≥2.50 m

≥2.50 m

≥8.00 m

≥18.00 m

>4.00 m >30.00 m

Installation

- → Assemble the sensor at the installation location.
- → Plug in the connector cable to the M12 connector, see Fig. 2.

2 • • 1 3 • 5 • 4		colour
1	+U _B	brown
3	−U _B	blue
4	-	black
2	I/U	white
5	Sync/Com	grey

Fig. 2: Pin assignment with view onto sensor plug and colour coding of the microsonic connection cable

Start-up

- → Connect the power supply.
- → Set the parameters of the sensor manually via TouchControl (see Fig. 3 and Diagram 1)
- → or use the Teach-in procedure to adjust the detect points (see Dia-

Notes

■ mic+ sensors have internal temperature compensation. Because the sensors heat up on their own, the temperature compensation reaches its optimum working point after approx. 30 minutes of operation.

WICLOLOUIC

- If an object is within the set window limits of the analogue output, then LED D1 lights up green, if the object is outside the window limits, then LED D1 lights up red.
- The load put to the analogue output is detected automatically when turning supply voltage on.
- During normal operating mode, the measured distance value is displayed on the LED-indicator in mm (up to 999 mm) or cm (from 100 cm). Scale switches automatically and is indicated by a point on top of the digits. Alternatively a percentage scale may be set in the add-on menu. In this connection 0 % and 100 % correspond to the set window limits of the analogue output.
- If no objects are placed within the detection zone the LED-indicator shows »---«.
- The sensor can be set to its factory setting, see Diagram 3.

Factory setting

Fig. 3: TouchControl/LED display

gram 2).

188

mic+ sensors are delivered factory made with the following settings: ■ Rising analogue characteristic

Measuring Range

3-digit

LED-display

-LED D1 and D2

Push-huttons T1 and T2

- Window limits for the analogue output set to blind zone and operating range
- Measurement range set to maximum range

Maintenance

mic+ sensors work maintenance free. Small amounts of dirt on the surface do not influence function. Thick lavers of dirt and caked-on dirt affect sensor function and therefore must be remo-

no push-buttons are pressed fo
) seconds during parameter set
ng mode the made changes are
ored and the sensor returns to
ormal operating mode.

Show parameters

→ In normal operating mode shortly push T1. The LED display shows

Each time you tap push-button T1 the actual settings of the analogue output are shown

Contact

Sensor Partners BV

- James Wattlaan 15 5151 DP Drunen The Netherlands
- +31 (0)416 37 82 39
- info@sensorpartners.com
- sensorpartners.com

Sensor Partners BVBA

- Z.1 Researchpark 310 B-1731, Zellik Belgium
- +32 (0)2 464 96 90
- info@sensorpartners.com
- sensorpartners.com



















