ECU Tool V0.3D Schematics CAN bus interface 12VDC to 5VD INTERFACE CAN_RST RESET CLKOUT KLINE TXD VSS VDD RXD RS CANH CANL VREF CS SCK SI SO 12V1> TX0RTS GND TX1RTS TX2RTS LEDs OSC1 OSC2 RX0BF RX1BF GND LED2 GND BUTTONS Programming Interface K-LINE Interface SD Interface MOSI (ISO_RX MISO GND GND VCC GND 5V> Mini Pro socket *Note for LCD: SDA and SCL are directly connected to the Mini Pro A4 and A5 GND (LED2) KOR GND CAN_RST CAN_CS OKBTN LFTBTN