

ALE-700A Action URL and Active URI Specifications

Version: <V1.0>

Release date: <2025-10-30>

Contents

1.	INTRODUCTION	3
1.1.	OVERVIEW	3
2.	ACTION URL	4
2.1.	INTRODUCTION	4
2.2.	PROTOCOL DESCRIPTION	4
2.3.	ACTION URL CONFIGURATION	4
2.4.	EVENT LIST	4
2.5.	VARIABLE LIST	5
2.6.	ACTION URL EXAMPLE	6
2.6.1.	SETUP COMPLETED	7
2.6.2.	REGISTRATION SUCCEEDED	7
2.6.3.	REGISTRATION DISABLED	7
2.6.4.	REGISTRATION FAILED	8
2.6.5.	START REBOOT	8
2.6.6.	CALL ESTABLISHED	8
2.6.7.	CALL TERMINATED	8
3.	ACTIVE URI	10
3.1.	INTRODUCTION	10
3.2.	SET ACTIVE URI LIMIT IP	10
3.3.	PROTOCOL TYPE	11
3.4.	INSTRUCTION LIST	11
3.5.	PROTOCOL DESCRIPTION	13
3.6.	SENDING A GROUP OF NUMBERS	13
3.7.	APPLICATION EXAMPLES	14
3.8.	SIP NOTIFY PUSH ACTIVE URI COMMAND	15
4.	INTERFACES FOR TROUBLESHOOTING	16
4.1.	EXPORT DEBUG DATA	16
4.2.	SCREENSHOT	16
4.3.	EXPORT LOG	16
4.4.	EXPORT PHONEBOOK	16
4.5.	PACKET CAPTURE	16
4.6.	EXPORT CONFIGURATION	17
4.7.	HTTP AUTHENTICATION	17

1. Introduction

1.1. Overview

The **Action URL** feature allows a telephone set to report its status to a remote console, while the **Active URI** feature enables a remote console to control various operations of the telephone set. Both Action URL and Active URI are primarily used in **Computer Telephony Integration (CTI)** scenarios, where the telephone set reports its current status to a PC, and the PC can perform remote operations on the telephone set.

A typical application example is a **call center**, where an attendant uses CTI software on a PC to operate the telephone set directly.

2. Action URL

2.1. Introduction

When the status of a telephone set changes, the telephone set sends an **HTTP GET** request to the remote console to report this event. The console can then perform corresponding operations on the telephone set based on the reported status change.

2.2. Protocol Description

The **Action URL** uses an HTTP request format defined by the HTTP server of the remote console. The telephone set is only responsible for initiating an **HTTP GET** request whenever a status change occurs.

In general, the format of the Action URL is as follows:

[http://192.168.1.100/newcall.xml?num=\\$call_id](http://192.168.1.100/newcall.xml?num=$call_id)

- 192.168.1.100 - IP address of the remote console.
- newcall.xml? - Indicates the method or script that handles different status events. This method is defined by the HTTP server on the remote console.
- \$call_id - Represents an internal variable of the telephone set. Before sending the HTTP GET request, the system automatically replaces this variable with its actual runtime value. Internal variables always begin with a dollar sign (\$).

2.3. Action URL Configuration

To configure the Action URL:

1. Log in to the management webpage of the telephone set.
2. Navigate to **Phone > Feature > Action URL Settings**.
3. Enter the desired URL in the corresponding text box for each event.

For example, enter the following URL for the **Incoming Call** event:

[http://192.168.1.100/newcall.xml?num=\\$call_id](http://192.168.1.100/newcall.xml?num=$call_id)

After configuration, when an incoming call from number **1234** is received, the telephone set automatically initiates the following HTTP GET request:

<http://192.168.1.100/newcall.xml?num=1>

2.4. Event List

Event	Description
Setup Completed	The telephone set is started successfully.
Registration Succeeded	An account is registered successfully.
Registration Disabled	Account registration is canceled.

Registration Failed	Account registration fails.
Phone Off Hooked	The telephone set is hooked off.
Phone On Hooked	The telephone set is hooked on.
Incoming call	A new incoming call is received.
Outgoing call	An outgoing call is made.
Call established	A call is connected.
Call terminated	A call is terminated.
DND Enabled	Do Not Disturb (DND) is enabled.
DND Disabled	DND is disabled.
Unconditional Call Forward Enabled	Unconditional call forwarding is enabled.
Unconditional Call Forward Disabled	Unconditional call forwarding is disabled.
Call Forward on Busy Enabled	Call forwarding on busy is enabled.
Call Forward on Busy Disabled	Call forwarding on busy is disabled.
Call Forward on No Answer Enabled	Call forwarding on no answer is enabled.
Call Forward on No Answer Disabled	Call forwarding on no answer is disabled.
Call transfer	Call transfer.
Unattended Call Transfer	Unattended call transfer.
Attended Call Transfer	Attended cal transfer.
Call hold	Call hold.
Call resume	Call hold is canceled.
Mute	A call is muted.
Unmute	A call is unmuted.
Missed calls	Missed calls are listed.
IP Changed	The IP address of the telephone set is changed.
Idle To Busy	The telephone set switches from the standby screen to other screens.
Busy To Idle	The telephone set switches from other screens to the standby screen.
MWI	Message.
SMS	SMS message.
Start reboot	The telephone set is restarted.

2.5. Variable List

Variable	Description
\$mac	Device MAC address.
\$ip	Current available IP address.
\$model	Model of the telephone set.
\$firmware	Software version.
\$active_uri	Session Initiation Protocol (SIP) URI of the current active account, which is valid in incoming calls, outgoing calls, and conversations
\$active_user	User account of the SIP URI of the current active account, which is valid in incoming calls, outgoing calls, and conversations
\$active_host	Server of the SIP URI of the current active account, which is valid in incoming calls, outgoing calls, and conversation
\$local	Local SIP URI (valid in incoming calls, outgoing calls, and conversations)
\$remote	Remote SIP URI (valid in incoming calls, outgoing calls, and

	conversations)
\$display_local	Local display name (phone number displayed if no display name is set) (valid in incoming and outgoing calls)
\$display_remote	Remote display name (phone number displayed if no display name is set) (valid in incoming and outgoing calls)
\$call_id	Call ID (valid in incoming calls, outgoing calls, and conversations)
\$duration	Call duration (valid when a conversation ends)
\$date_time	Acquisition time
\$memory_free	Memory
\$flash_free	Flash memory
\$line	Call line (valid in incoming calls, outgoing calls, conversations, and registration)
\$local_user	Local users in a conversation (valid in incoming calls, outgoing calls, and conversations)
\$local_server	Server used in a SIP call (valid in incoming calls, outgoing calls, and conversations)
\$local_domain	Domain of a SIP cal (valid in incoming calls, outgoing calls, and conversations)
\$local_number	Local phone number during a call (valid in incoming calls, outgoing calls, and conversations)
\$local_displayname	Display name of the local phone number during a call (valid in and conversations)
\$remote_number	Remote phone number (valid in outgoing calls before they are answered)
\$remote_displayname	Display name of the remote phone number during a call (valid in incoming calls, outgoing calls, and conversations)

Variable description:

- 1) **Variables valid only for incoming calls**
These variables are replaced with the corresponding information **only** when they are configured in **Incoming Call** event options.
- 2) **Variables valid only for outgoing calls**
These variables are replaced with the corresponding information **only** when they are configured in **Outgoing Call** event options.
- 3) **Variables valid only during conversations**
These variables are replaced with the corresponding information **only** when they are configured in conversation-related event options, such as:
 - Call Established**
 - Call Terminated**
 - Transfer Call**
 - Blind Transfer Call**
 - Attended Transfer Call**
 - Hold / Unhold**
 - Mute / Unmute**

2.6. Action URL Example

It is useful for users to collect some of the events listed in section 2.4, as they help users monitor the status of phones.

A backend program on the HTTP server side can be developed to parse the received HTTP messages. In the examples below, each event is handled by a separate program, but it is also

possible to use a single program to handle all events by identifying the event type from the Action URL.

The max length of the configurable action URL is 256bytes.

2.6.1. Setup Completed

When configured correctly, this Action URL is sent to the specified HTTP server after the ALE-700A phone completes initialization.

For example, when the action URL of “Setup Completed” is configured to:

[http://192.168.1.100/setup_completed?mac=\\$mac&ip=\\$ip&model=\\$model&fw=\\$firmware&dt=\\$date_time](http://192.168.1.100/setup_completed?mac=$mac&ip=$ip&model=$model&fw=$firmware&dt=$date_time)

When an ALE-700A completes initialization procedure, it will send a HTTP GET message like:

[setup_completed?mac=00a859ebf35b&ip=10.10.6.141&model=ALE-700A&fw=2.6.10.2781.22&dt=2025917163145](http://192.168.1.100/setup_completed?mac=00a859ebf35b&ip=10.10.6.141&model=ALE-700A&fw=2.6.10.2781.22&dt=2025917163145)

2.6.2. Registration Succeeded

When configured correctly, this Action URL is sent to the specified HTTP server after the ALE-700A phone successfully registers **with** the SIP server.

For example, when the action URL of “Registration Succeeded” is configured to:

[http://192.168.1.100/registration_succeed?mac=\\$mac&ip=\\$ip&lc=\\$local&line=\\$line&dt=\\$date_time](http://192.168.1.100/registration_succeed?mac=$mac&ip=$ip&lc=$local&line=$line&dt=$date_time)

When an ALE-700A registered successfully on a SIP server, it will send a HTTP GET message like:

[registration_succeed?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&line=1&dt=2025917163146](http://192.168.1.100/registration_succeed?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&line=1&dt=2025917163146)

Backend program may need to parse the variable \$local to get the number/server IP/server port.

2.6.3. Registration Disabled

When configured correctly, this Action URL is sent to the specified HTTP server after the ALE-700A phone’s registration is disabled.

For example, when the action URL of “Registration Disabled” is configured to:

[http://192.168.1.100/registration_disabled?mac=\\$mac&ip=\\$ip&lc=\\$local&line=\\$line&dt=\\$date_time](http://192.168.1.100/registration_disabled?mac=$mac&ip=$ip&lc=$local&line=$line&dt=$date_time)

When an ALE-700A disabled its registration, it will send a HTTP GET message like:

[registration_disabled?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&line=1&dt=2025917163146](http://192.168.1.100/registration_disabled?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&line=1&dt=2025917163146)

Backend program may need to parse the variable \$local to get the number/server IP/server port.

2.6.4. Registration Failed

When configured correctly, this Action URL is sent to the specified HTTP server **after the ALE-700A phone fails to register with the SIP server.**

For example, when the action URL of “Registration Failed” is configured to:

[http://192.168.1.100/registration_fail?mac=\\$mac&ip=\\$ip&lc=\\$local&line=\\$line&dt=\\$date_time](http://192.168.1.100/registration_fail?mac=$mac&ip=$ip&lc=$local&line=$line&dt=$date_time)

When an ALE-700A fails to register with a SIP server, it will send a HTTP GET message like:

[registration_fail?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&line=1&dt=2025917163146](http://192.168.1.100/registration_fail?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&line=1&dt=2025917163146)

Backend program may need to parse the variable \$local to get the number/server IP/server port.

2.6.5. Start reboot

When configured correctly, this Action URL is sent to the specified HTTP server **when it is rebooted.**

For example, when the action URL of “Start reboot” is configured to:

[http://192.168.1.100/start_reboot?mac=\\$mac&ip=\\$ip&lc=\\$local&line=\\$line&dt=\\$date_time](http://192.168.1.100/start_reboot?mac=$mac&ip=$ip&lc=$local&line=$line&dt=$date_time)

When an ALE-700A starts rebooting, it will send a HTTP GET message like:

[start_reboot?mac=00a859ebf35b&ip=10.10.6.141&lc=ALE-700A&fw=2.6.10.2781.22&dt=2025917163145](http://192.168.1.100/start_reboot?mac=00a859ebf35b&ip=10.10.6.141&lc=ALE-700A&fw=2.6.10.2781.22&dt=2025917163145)

2.6.6. Call established

When configured correctly, this Action URL is sent to the specified HTTP server **when a call is established.**

For example, when the action URL of “Call established” is configured to:

[http://192.168.1.100/call_established?mac=\\$mac&ip=\\$ip&lc=\\$local&rm=\\$remote&dl=\\$display_local&dr=\\$display_remote&cid=\\$call_id&dt=\\$date_time](http://192.168.1.100/call_established?mac=$mac&ip=$ip&lc=$local&rm=$remote&dl=$display_local&dr=$display_remote&cid=$call_id&dt=$date_time)

When an ALE-700A establishes a call, it will send a HTTP GET message like:

[call_established?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&rm=SIP:2001@10.10.6.66:15060&dl=John%20Doe&dr=Jane%20Doe&cid=3&dt=20251131045](http://192.168.1.100/call_established?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&rm=SIP:2001@10.10.6.66:15060&dl=John%20Doe&dr=Jane%20Doe&cid=3&dt=20251131045)

Backend program may need to parse the variable \$local/\$remote to get the number/server IP/server port of caller and callee.

2.6.7. Call Terminated

When configured correctly, this Action URL is sent to the specified HTTP server **when a call is terminated.**

For example, when the action URL of “Call terminated” is configured to:

[http://192.168.1.100/call_terminated?mac=\\$mac&ip=\\$ip&lc=\\$local&rm=\\$remote&dl=\\$display_l](http://192.168.1.100/call_terminated?mac=$mac&ip=$ip&lc=$local&rm=$remote&dl=$display_l)

ocal&dr=\$display_remote&cid=\$call_id&dr=\$duration&dt=\$date_time

When an ALE-700A terminates a call, it will send a HTTP GET message like:

call_terminated?mac=00a859ebf35b&ip=10.10.6.141&lc=SIP:1007@10.10.6.66:15060&rm=SIP:
2001@10.10.6.66:15060&dl=John%20Doe&dr=Jane%20Doe&cid=3&dr=00:00:42&dt=20251131
0447

Backend program may need to parse the variable \$local/\$remote to get the number/server IP/server port of caller and callee.

3. Active URI

3.1. Introduction

The remote console initiates an **HTTP GET** request to the telephone set.

The **embedded HTTP server** of the telephone set parses the instruction and responds accordingly, enabling remote control of the device.

3.2. Set Active URI Limit IP

To restrict which remote consoles are permitted to control the telephone set, you can configure the **Active URI Source IP** parameter.

Navigate to:

Web Page → Phone Settings → Features → Active URI Source IP

Restrict Active URI Source IP Parameter states:

Parameter name	Restrict Active URI Source IP
Parameter description	1. Push the active URI command to HTTP protocol: 1) When the IP list is not empty, only the filled IP can send HTTP active URI command to the phone. 2) When the IP list is empty, the phone accepts any HTTP active URI commands pushed by IP 2. The active URI command pushed by SIP notify: 1) Notify from registered SIP server Do not check the IP restriction list, accept by default. 2) IP is empty. Any IP other than SIP registration server sends active URI through SIP notify, and the phone does not respond IP is not empty. Only the listed IP and sip registration server IP can operate the phone directly. When the IP in the list sends the SIP notify message of event: active-uri to the phone, the phone will respond directly without pop-up prompt
Effective value	IP address
Default value	Empty

3.3. Protocol type

Active URI supports both **HTTP** and **HTTPS** protocols, depending on the **Web Protocol** configured on the ALE-700A.

The Web Protocol can be configured via the **WBM interface (Network → Service Port → Web Server Type)** or through **configuration files**.

3.4. Instruction List

Access dial	
key=SPEAKER key= F_HANDFREE key= F HANDSFREE	Hands free key, turn on and off handsfree
F_HEADSET (or key=HEADSET)	Headset key
key=F Prefix: prefix number key = f_Prefix; prefix number	prefix
Answer the phone	
key=OK key=ENTER key=F_OK	Confirm key, you can answer the phone; pick up the phone; send the number; enter the menu under standby
key=F_ACCEPT	Answer key
CALL	
key=SPEAKER;0000;ENTER	Call with handsfree carrying number 0000
key=0000;ENTER	Call with number 0000 in standby mode
key=F_LOR	call back number
key=F_HEADSET;000;ENTER key=HEADSET;000;ENTER	Headset mode carries the number 000 to initiate a call
key=RD key=F_REDIAL	Redial the number and press the redial key
F_SEND	When there is a number on the dial, sending out the number is the same as pressing the daily key
Hang up or reject	
key=RELEASE key=F_RELEASE	It's the same as pressing release Hang up, refuse to answer, quit dialing, etc
key=F_CANCEL key=X	It's the same as pressing cancel
key=F_REJECT	It's the same as pressing the reject key
transfer	
key=F_TRANSFER key=F_B_TRANSFER key=F_A_TRANSFER	It works the same as pressing the transfer. It can realize blind transfer, present transfer and semi attendance transfer. Exit an application interface, etc.
key=F_TRANSFER;0000;OK	Call 0000
key=F_TRANSFER;000;F_A_TRANSFER	Blind to 000
key=F_DIVERT	Call forwarding
conference	
key=F_CONFERENCE	The same effect as pressing the conference key will enter the conference dialing interface
key=F_JOIN	Join a three-way call just like pressing dsskey join
Advanced call function	
key=DND	On / off dnd

key=DNDON	On DND
key=DNDOFF	Off DND
F_PICKUP	It is the same as pressing dsskey pickup to answer the call and call normally
key=F_PARK	As with pressing dsskey Park, the call is resident
key=F_AUTOREDIAL	As with pressing dsskey automatic, automatic dialing (which takes effect when dialing)
key=F_UNAUTOREDIAL	The same as pressing dsskey unautoredial, cancels the automatic dialing (it takes effect when dialing)
key=1234	In the call state, input DTMF 1234 continuously
key=F_HOLD	Hold / release hold
key=F_0-9/*/POUND	Enter a single DTMF number (including numeric keys and *)
key=* key=F_* key=F_STAR	*Key
key=# key=POUND key=F_POUND	# Key
F_REC	Recording during a call
key=F_FLASH	Switching calls / answering calls during calls
key=F_GROUPLISTEN	Group listening
modulation	
key=VOLUME_UP key=F_VOLUME_UP	It works the same as pressing the volume down button The volume can be turned up in talking, conf, idle and other states
key=VOLUME_DOWN key=F_VOLUME_DOWN	Reduce the volume
key=F_MUTE MUTE	Silence
Enter the app	
key=F_AGENT	Enter the agent configuration interface
key=MSG key=F_MWI	Access to voice mail
key=F_MEMO	Enter memo
key=F_PBOOK	Access to the phone book
key=F_LOCALCONTACTS	Local phone book
key=F_SERVICE	Access to Internet phone book
key=F_SMS	Enter the SMS interface
key=F_LOCK	Enter the keyboard lock configuration
key=F_SDTMF	interface Enter the hide DTMF configuration interface
key=F_CFWD	Enter call forwarding settings
Modify configuration / restart / restore factory settings	
key=F_HOTDESKING	Clear SIP configuration
key=Reboot key=F_REBOOT	restart
key=AutoP	Restart auto provision detection
line=x;displayname=xxxxx	Modify the display name of X line
key=Reset	Restore factory settings
Navigation key / delete key / menu key	
key=UP/key=F_UP	Navigation key up
key=DOWN/F_DOWN	Navigation key down
key=LEFT/F_LEFT	Navigation key left
key=RIGHT/F_RIGHT	Navigation key right

key=OK	Navigation key OK
key= F_DELETE key=DELETE	Delete key

3.5. Protocol Description

The **Active URI** command is transmitted through an HTTP GET request. The general format of the HTTP URL is as follows:

<http://192.168.1.190/cgi-bin/ConfigManApp.com?key=OK>

- **192.168.1.190** – The IP address of the telephone set.
- **/cgi-bin/ConfigManApp.com** – A fixed path used for Active URI commands. The telephone set parses this path and interprets it as a remote-control instruction.
- **?key=OK** – The operation parameter, indicating the action to be performed by the telephone set. In this example, the instruction simulates an **OK key press** event.

HTTP Authentication

For security reasons, HTTP authentication is enabled by default on telephone sets. When authentication is required, the HTTP URL must include valid credentials, as shown below:

<http://admin:admin@192.168.1.190/cgi-bin/ConfigManApp.com?key=OK>

admin:admin – The default username and password for the embedded HTTP server of the telephone set.

These credentials are the same as those used to log in to the phone's web management interface.

3.6. Sending a Group of Numbers

The Active URI command described above supports only one operation per request. For example, when entering a number, only a single key event can be processed at a time, which makes multi-digit input cumbersome.

To simplify such operations, Active URI also supports sending a group of numbers within a single URL request. Multiple key events can be concatenated using semicolons (“;”).

Example 1: Initiating a Call with a Number

<http://admin:admin@192.168.1.190/cgi-bin/ConfigManApp.com?key=SPEAKER;000;ENTER>

When the telephone set receives this instruction in **standby mode**, it performs the following actions sequentially:

- 1) Activates **hands-free off-hook** mode (SPEAKER).
- 2) Enters the number **000**.
- 3) Confirms and **initiates the call** automatically (ENTER).

Example 2: Blind Transfer with a Number

http://admin:admin@192.168.1.190/cgi-bin/ConfigManApp.com?key=F_TRANSFER;000;F_TRANSFER

When the telephone set receives this instruction **during an active call**, it automatically performs a **blind transfer** of the current call to number **000**.

3.7. Application Examples

The **Active URI** feature can be used in call centers and other CTI environments to remotely control telephone sets and automate call operations such as answering calls, handling multiple lines, switching between calls, and performing call transfers.

Below are several typical application examples:

1) Answering a Call

When an incoming call is received, the console can send the following command to answer it:

http://phone_IP/cgi-bin/ConfigManApp.com?key=OK

This command simulates pressing the **OK** key on the phone to answer the call.

2) Answering a Second Call

When a second incoming call arrives during an active conversation, send the same command:

http://phone_IP/cgi-bin/ConfigManApp.com?key=OK

The phone will automatically place the **first call on hold** and answer the **second call**.

3) Switching Between Two Calls

There are two methods to switch between active and held calls:

Method 1 – Using F_Flash Command:

If the telephone currently has three calls (A, B, and C), with **A active** and **B/C on hold**, send:

http://phone_IP/cgi-bin/ConfigManApp.com?key=F_Flash

This command switches the active channel. After execution, **B becomes active**, while **A and C** are placed on hold.

Method 2 – Using prev_Call / next_Call and F_Hold Combination:

Alternatively, you can manually select and resume a specific call:

http://phone_IP/cgi-bin/ConfigManApp.com?key=prev_Call

(or)

http://phone_IP/cgi-bin/ConfigManApp.com?key=next_Call

Then use the following command to resume the selected call:

http://phone_IP/cgi-bin/ConfigManApp.com?key=F_Hold

You can choose either method depending on the specific call control requirements.

4) Transferring the Second Call

To perform an attended transfer:

- a) Use the method described in step 3) to switch to the second call (the call can be in hold or active state).
- b) Send the following command to transfer the call to number 0000 (or another number):

http://phone_IP/cgi-bin/ConfigManApp.com?key=F_Transfer;0000;OK

After the transfer target (0000) answers, send:

<http://phone IP/cgi-bin/ConfigManApp.com?key=OK>

to **complete the attended transfer**.

3.8. SIP Notify Push Active URI Command

1. Notify format

When a SIP **NOTIFY** message with the event type **Active URI** is received by the phone, the instruction contained in the message body in the format **key=XXX** will be executed by the phone (the receiver of the message).

Notice format reference:

```
NOTIFY sip:3583@10.2.40.10:5062 SIP/2.0
Via: SIP/2.0/UDP 10.2.40.27:5063;branch=z9hG4bK4163876675
From: <sip:3586@10.2.1.48 > ;tag=2900480538
To: "3583" <sip:3583@10.2.1.48 > ;tag=490600926
Call-ID: 2923387519@10.2.40.10
CSeq: 4 NOTIFY
Contact: <sip:3586@10.2.40.27:5063 >
Max-Forwards: 70
User-Agent: ALE-700A
Event: ACTIVE-URI
Content-Type: message/sipfrag
Content-Length: 6

key=OK
```

2. IP limit of push SIP notify command: refer to [3.2 Active URI Limit IP](#).

3. Uri Directive: Reference [3.3 Instruction List](#).

4. Interfaces for troubleshooting

4.1. Export Debug Data

Similar to the operation available via **WBM → System → Tools → Export Debug Data**, the debug package can also be retrieved using the CGI interface `exportFile`.

Authentication (username and password) is mandatory to access this CGI.

Example:

```
curl -vvv -u "admin:{password}" -JO http://30.1.71.22/cgi-bin/exportFile?type=debugInfoExport
```

Note:

This command may take some time to complete, as the system needs to compress and package the collected debug data before sending.

The exported data is primarily used for debugging purposes, such as analyzing the cause of an application crash.

4.2. Screenshot

Similar to **WBM → System → Tools → Screenshot**, a screenshot of the current phone screen can be captured through the CGI interface `scnShot`.

Authentication (username and password) is mandatory to access this CGI.

Example:

```
curl -vvv -u "admin:{password}" -JO http://30.1.71.22/cgi-bin/scnShot?type=main
```

4.3. Export Log

Similar to **WBM → System → Tools → Export Log**, system logs can be exported through the CGI interface `syslog`.

Authentication (username and password) is mandatory to access this CGI.

Example:

```
curl -vvv -u "admin:{password}" -JO http://30.1.71.22/cgi-bin/syslog?type=syslog
```

Note:

This command is only valid when **syslog** is **disabled** and the “Export Log” option is **enabled**.

4.4. Export Phonebook

Similar to **WBM → Phonebook → Advanced → Export Contact List**, the phonebook entries can be exported in multiple formats through the CGI interface `phonebook`.

Authentication (username and password) is mandatory to access this CGI.

Example:

```
curl -vvv -u "admin:{password}" -JO http://30.1.1.22/cgi-bin/phonebook?type=xml  
curl -vvv -u "admin:{password}" -JO http://30.1.1.22/cgi-bin/phonebook?type=csv  
curl -vvv -u "admin:{password}" -JO http://30.1.1.22/cgi-bin/phonebook?type=vcf
```

4.5. Packet Capture

Similar to **WBM → System → Tools → Packet Capture**, network traffic can be captured through the CGI interface `WebCapture`.

Authentication (username and password) is mandatory to access this CGI.

Example:

```
curl -vvv -u "admin:{password}" -JO http://30.1.1.22/cgi-bin/WebCapture?type=Start
```

Note:

The capture will continue until it is manually stopped. After stopping, the captured .pcap file can be downloaded using the same CGI command.

4.6. Export Configuration

Similar to **WBM** → **System** → **Configurations** → **Export Configurations**, the effective configuration parameters can be exported directly by accessing the following resource paths.

Authentication (username and password) is mandatory to access these files.

Example:

```
curl -vvv -u "admin:{password}" -H "Connection: close" -JO http://30.1.1.22/default\_user\_config.txt
```

```
curl -vvv -u "admin:{password}" -H "Connection: close" -JO http://30.1.1.22/ncConfig.txt
```

```
curl -vvv -u "admin:{password}" -H "Connection: close" -JO http://30.1.1.22/default\_user\_config.xml
```

4.7. HTTP Authentication

All troubleshooting interfaces require Basic HTTP Authentication.

Below is an example of an authenticated request captured in a packet trace:

```
Frame 44: Packet, 227 bytes on wire (1816 bits), 227 bytes captured (1816 bits)
Linux cooked capture v1
Internet Protocol Version 4, Src: 135.251.222.230, Dst: 10.10.6.141
Transmission Control Protocol, Src Port: 50938, Dst Port: 80, Seq: 1, Ack: 1, Len: 159
Hypertext Transfer Protocol
  GET /default_user_config.txt HTTP/1.1\r\n
  Host: 10.10.6.141\r\n
  Authorization: Basic YWRtaW46KnR4ODAwMCM=\r\n
  User-Agent: curl/8.5.0\r\n
  Accept: */*\r\n
  Connection: close\r\n
\r\n
[Response in frame: 330]
[Full request URI: http://10.10.6.141/default\_user\_config.txt]
```