HEGduino alpha


Quick update guide.

12/12/19

Step 1: Download the latest update file, which is a .bin file. It is available in the github repo here: <a href="https://github.com/moothyknight/HEG\_ESP32">https://github.com/moothyknight/HEG\_ESP32</a>. Simply download or clone the folder to get the .bin file from the HEG\_WIFI\_BLE folder.

Step 2: Connect to your HEG's WiFi signal with password "12345678"

Step 3: In a web browser (preferably Chrome or Firefox), enter the address "192.168.4.1/update" to come to the update page.



Step 4: Hit the Browse button and find the downloaded update file

Step 5: Hit Update. Wait a few minutes as it should freeze up while updating.

Step 6: Reconnect and test your output via the Canvas Demo from "192.168.4.1" in the browser, you can check the Console of your browser to see if the signal is outputting correctly if nothing shows up in the data table. Right click the page and hit "Inspect" or "Inspect element" to bring up your side console. If the console tab is not selected, select it to see an output stream (image on next page)

