a

```
Router>
Router>enable
Router#disable
Router>
```

b

```
Router>
Router>enable
Router#configure terminal
Enter configuration commands, one per line.  End with
Router(config)#exit
Router#
%SYS-5-CONFIG_I: Configured from console by console
```

c

```
Router#show version
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-I-M), Version 12.2(28), RELEASE SOFTWARE
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2005 by cisco Systems, Inc.
Compiled Wed 27-Apr-04 19:01 by miwang
Image text-base: 0x8000808C, data-base: 0x80A1FECC

ROM: System Bootstrap, Version 12.1(3r)T2, RELEASE SOFTWARE (fc1)
Copyright (c) 2000 by cisco Systems, Inc.
ROM: C2600 Software (C2600-I-M), Version 12.2(28), RELEASE SOFTWARE (fc5
```

d

```
Router#show ip protocol
Routing Protocol is "rip"
Sending updates every 30 seconds, next due in 22 seconds
Invalid after 180 seconds, hold down 180, flushed after 240
Outgoing update filter list for all interfaces is not set
Incoming update filter list for all interfaces is not set
Redistributing: rip
Default version control: send version 2, receive 2
  Interface             Send  Recv  Triggered RIP  Key-chain
Automatic network summarization is in effect
Maximum path: 4
Routing for Networks:
      10.0.0.0
      192.168.1.0
Passive Interface(s):
Routing Information Sources:
      Gateway         Distance      Last Update
Distance: (default is 120)
Router#
```

e

```
2501A#show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - m
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA exte
       E1 - OSPF external type 1, E2 - OSPF external type
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2,
       * - candidate default, U - per-user static route, o
       P - periodic downloaded static route

Gateway of last resort is not set

     172.16.0.0/24 is subnetted, 5 subnets
C       172.16.10.0 is directly connected, FastEthernet0/0
C       172.16.20.0 is directly connected, Serial0/0
S       172.16.30.0 [1/0] via 172.16.20.2
S       172.16.40.0 [1/0] via 172.16.20.2
S       172.16.50.0 [1/0] via 172.16.20.2
```

f

```
Router#copy running-config startup-config
Destination filename [startup-config]?
Building configuration...
[OK]
```

g

```
Router#show history
  show ip protocols
  enable
  configure terminal
  show ip protocol
  enable
  configure terminal
  show ip route
  copy running-config startup-config
  hi
  show history
```

h

```
Router#show clock
*0:15:53.439 UTC Mon Mar 1 1993
```

J

```
Router#show ip interface brief
Interface              IP-Address      OK? Method Status                Protocol
FastEthernet0/0        192.168.1.1     YES manual down                  down
FastEthernet0/1        unassigned      YES unset  down                  down
```

i

```
Router#show hosts
Default Domain is not set
Name/address lookup uses domain service
Name servers are 255.255.255.255

Codes: UN - unknown, EX - expired, OK - OK, ?? - revalidate
       temp - temporary, perm - permanent
       NA - Not Applicable None - Not defined

Host                      Port  Flags      Age Type   Address(es)
PC1                       None  (perm, OK)  0   IP      192.168.1.101
Server1                   None  (perm, OK)  0   IP      192.168.1.100
```

k

```
2501C#show controllers serial 0/0
Interface Serial0/0
Hardware is PowerQUICC MPC860
DTE V.35 TX and RX clocks detected
idb at 0x81081AC4, driver data structure at 0x81084AC0
```

l i

```
Router#enable
Router#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)#interface FastEthernet 0/0
Router(config-if)#ip address 192.168.1.1 255.255.255.0
Router(config-if)#no shutdown

Router(config-if)#exit
```

l ii

```
Router>enable
Router#configure terminal
Enter configuration commands, one per line.  End with
Router(config)#interface serial 0/0
Router(config-if)#ip address 10.0.0.1 255.255.255.252
Router(config-if)#clock rate 64000
Router(config-if)#no shutdown
Router(config-if)#exit
Router(config)#end
Router#
```