

02135 Assignment 3 and 4 FAQs

How do I remove the main.py file when Ampy cannot connect because the ESP32 is busy running the main.py itself?

The main.py file can be deleted from the Python shell using the serial terminal (e.g., Putty). Once connected to the serial terminal. Interrupt the execution of the current program (CTRL+C) and delete the file using the following commands:

```
import uos  
uos.remove("main.py")
```

What is the speed of the serial port for communicating with the ESP32 board?

Baud rate: 115200

My ESP32 board is misbehaving or it seems dead. What should I do?

Ask Luca to flash the board (takes less than 5 minutes) or for a replacement.

I burned/destroyed some component or I need additional components to implement advanced/alternative functionality (resistors, capacitors, ICs, etc.). What should I do?

Ask Haris for a replacement or to bring what you need.