

## Manage dual SIMs

### About dual SIMs

If you're [using a physical SIM and an eSIM](#):

- You see  at the top of the home screen. If you see , [troubleshoot the issue](#).
- Both SIMs can make and receive calls and text messages.
- Only the [owner](#) of the phone (not additional users or guests) can access dual SIM settings.

### Set up SIMs

#### Set SIMs for calling

1. Go to [Settings](#) > **Network & internet** > **SIMs & mobile network**.
2. Adjust settings under **Calling**:
  - To use one SIM for all calls, select the SIM.
  - To choose a SIM each time you make a call, select **Always ask**.
  - To automatically assign a SIM to a contact after you use it to call three times, turn **Smart SIM** on . You can always change this by manually assigning a SIM.
  - To manually assign a SIM to one or more contacts, tap **Assign a SIM to a contact**, then go to the SIM tab and select the contacts.

#### Choose preferred SIM for messages

You can choose a preferred SIM to use for messages. When you do, you'll see it as the default in the text field of the  Messages app.

1. Go to [Settings](#) > **Network & internet** > **SIMs & mobile network**.
2. Under **SIM for messages**, select the SIM.

To [send a message](#) from your other SIM, in the  Messages app, tap  and select the SIM.

#### Choose preferred SIM for mobile data

1. Go to [Settings](#) > **Network & internet** > **SIMs & mobile network**.
2. Tap **SIM for mobile data**.
3. Select your preferred SIM.
4. Choose how you want to handle mobile data if your preferred SIM can't connect:
  - If you want to use your other SIM, turn **Switch SIM automatically** on .
  - If you never want to use your other SIM for mobile data, turn **Switch SIM automatically** off .