
Set up voicemail

Set voicemail password

Contact your carrier for help setting or recovering your password/PIN for voicemail.

Set mailbox greeting

Your carrier provides and manages your voicemail.

To set your greeting:

1. Touch  > .
2. Touch & hold  to dial into your mailbox.
3. Follow your carrier's system prompts. If your voicemail is not set up, contact your carrier for instructions.

Change voicemail options

1. Touch  >  > **Settings**.
(If you don't see , swipe down on the screen.)
2. Touch **Voicemail**.
3. If you have two SIMs, touch the SIM for the account to change.
4. Change any of the options:
 - To change voicemail service from your carrier to a different service or app, touch **Advanced Settings** > **Service**.
 - To change the number dialed to access voicemail, touch **Advanced Settings** > **Setup**.
 - Your carrier might include additional options here, like notification and visual voicemail settings. Contact your carrier for help.