

Open all settings

To open the full list of all settings:

- [Open quick settings](#) and tap .
- Or, [open](#) the  **Settings** app.

Tip: Search the Settings app to find what you need quickly. Just tap  at the top of the app and type your search term.

Customize quick settings

Add, remove, rearrange quick settings

You can rearrange quick settings, putting your most used at the top. You can also add or remove them.

1. Open quick settings.
2. Tap .
3. Drag tiles to rearrange. Or swipe up to add new tiles.

To return quick settings to its original state, tap  > **Reset**.

Pin/unpin media player in quick settings

When you leave a media app that allows you to listen in the background while you use other apps on your phone, playback switches to the media player, which opens in quick settings and also appears on your lock screen for convenient control.

To let you continue listening from where you left off, the media player is pinned to its spot in quick settings. When it's pinned, you can't swipe it to close it.

To swipe the media player to close it and remove it from quick settings until you play something again, unpin it:

1. Open quick settings, touch & hold the media player, and touch .
Or, go to **Settings > Sound & vibration > Media**.
2. Turn **Pin media player** off .

To pin the media player to its spot in quick settings:

1. Open quick settings, touch & hold the media player, and tap .
Or, go to **Settings > Sound & vibration > Media**.
2. Turn **Pin media player** on .

Apps that support background playback

While some apps like YouTube and require a premium paid subscription to play in the background and won't open in the media player using the free version, many media apps such as Spotify, Pandora, and Amazon Music do support background playback in their free versions.

To find more apps, open [Play Store](#) and  search for "free background playback".