

Change style for quick settings & notifications

1. Go to **Settings > Home & lock screen > Control center**.
2. Choose the option you want:
 - To see quick settings and notifications together on the same screen when you swipe down from the top, select **Classic style**.
 - To separate quick settings and notifications on individual screens when you swipe down from the top RIGHT (quick settings) or top LEFT (notifications), select **Modern style**.

Show/hide quick settings & notifications on lock screen

1. Go to **Settings > Home & lock screen > Control center**.
2. To access quick settings and notifications from the lock screen, turn on **Allow access to quick settings and notifications drawer on Lock screen**.

Or to hide them from the lock screen, so you can only see them after unlocking the phone, turn it off .