

4. If you want more control of playback, tap the recording to open it in the full player. Then use icons as needed:

Icon	Action
	Tap to increase/decrease playback speed.
	Drag to skip to a specific point in the recording.
	Tap to skip forward a few seconds.
	Tap to skip backward a few seconds.
	Tap to adjust looping.

Trim a recording

1. In the  **Recorder** app, tap the recording.
2. Tap .
3. Drag the handles around the audio to save.
4. Tap **Trim** to cut away the audio outside the handles.
5. Tap **Save**, then choose **Save as copy** to retain the original audio file and the trimmed version, or tap **Save** to save only the trimmed audio file.

Manage recordings

Add or remove favorites

Find recordings easily by adding them to your favorites:

1. [Open](#) the  **Recorder** app.
2. Next to the recording, tap .
3. Tap  to add it to favorites, or tap  to remove it.

Rename, delete, share, or view details

1. [Open](#) the  **Recorder** app.
2. Next to the recording, tap .