

Customize your Favorites tray

The Favorites tray at the bottom of your [home screen](#) gives you quick access to your most-used apps. You can customize the shortcuts in this tray.



Change app shortcuts manually

1. Touch & hold one of the app shortcuts, then drag it up and drop it on **Remove**.
2. Swipe up from the bottom of the home screen to open your app list.
3. Touch & hold the app you want. When the new shortcut appears, drag it to the empty spot in your tray.

Tip: You can also use [folders](#) in your Favorites tray.

Change app shortcuts automatically, based on usage

To have your phone automatically update these shortcuts with apps you use most often:

1. Touch & hold a blank space on your home screen.
2. Tap  **Home settings** > **Home screen style**.
3. Next to **App tray**, tap .
4. Turn **Suggestions on Home screen** on .

Fix an issue

If the apps in your Favorites tray are being replaced by apps you haven't selected and you don't want them to change, [try these troubleshooting steps](#).