
Use Airplane mode

Airplane mode turns off all wireless connections on your phone to prevent it from transmitting signals that could interfere with airplane communications.

Turn it on

Open [quick settings](#) and tap  to turn airplane mode on. This disables all wireless connections (Wi-Fi, voice and data for calls and text messages, Bluetooth). If your airline permits it, you can then turn [Wi-Fi](#) and/or [Bluetooth](#) back on during the flight. Other wireless connections will remain off.

Turn it off

Open [quick settings](#) and tap .