

Make contactless payments

Only some versions of this phone, sold in certain countries, support this feature.

Use NFC (near-field communication) to pay quickly and [securely](#) at checkout registers by touching your phone to an electronic reader.

Set up contactless payment

1. Make sure you have:
 - Set up a payment app on your phone. [Install one](#) from Play Store if needed.
 - Turned on [NFC](#).
2. Go to [Settings](#) > **Connected devices** > **Connection preferences**.
3. Tap **NFC** and make sure it's on.
4. Tap **Contactless payments** and adjust settings:
 - To change payment apps, tap **Default payment app** and select the app.
 - If you have multiple payment apps, tap **Use default payment app**, then chose when to use your default app (always or except when another payment app is open).

Note: This feature manages payment apps. It doesn't include money transfer apps.

Make a payment

1. Make sure [NFC is on](#) and that the terminal has this symbol:



2. Unlock your phone and tap its [back](#) to the terminal.

Your payment app might require you to open the app and enter a PIN before touching your phone to the terminal.

Turn off contactless payment

[Turn off NFC](#).

Tip: You can also open your payment app and turn off contactless payments. Not all payment apps support this option.