

Cast personal media with Wi-Fi Direct

If your TV supports Wi-Fi Direct, [set up a connection](#) between your phone and TV so that you can view or play media from your phone.

For information about using Wi-Fi Direct after you've connected, see the user guide that came with your TV.

Fix an issue

After each step, see if your issue is fixed.

Check the basics

1. If you're using a [VPN](#), turn off the VPN and try again.
2. Make sure your phone and Chromecast or smart TV are connected to the same [Wi-Fi](#) network.
3. Move your phone to within 15 feet of your Chromecast or smart TV.
4. If you're using Chromecast or a TV with Chromecast built-in, [check for updates](#) to the Home app.

Phone can't find smart TV

First, check the basics. Then:

1. On the TV, open the app and start a video. Then on your phone, open the app and try casting to the TV again.
2. Link the app on your phone to the app on the TV:
 - a. On your phone, open the app, open its settings, and look for options to watch on TV. (For example, **YouTube** >  > **Settings** > **Watch on TV** > **Link with TV code.**)
 - b. Follow the app's onscreen instructions to complete setup.
3. Reboot your Wi-Fi router.
4. Check your TV for firmware and app updates. See the TV manufacturer's support website for information.
5. Check your TV manufacturer's support website to make sure the app is still supported on your TV model.

Check for app help

If you're having issues casting with one of these apps, check their help center for troubleshooting information:

- [Netflix](#)
- [Amazon Prime Video](#)
- [YouTube](#)
- [Google TV](#)