

Change vibration settings

Turn all vibration on/off

Turning vibration off is a good way to [extend battery life](#) when you need to.

To control overall phone vibration (calls, notifications, keyboard interactions) with one on/off switch:

1. Go to [Settings](#) > **Sound & vibration** > **Vibration & haptics**.
2. Turn **Use vibration & haptics** on  or off .

Set call vibration

Prevent your phone from vibrating for calls

1. Go to [Settings](#) > **Sound & vibration**.
2. Tap **Vibration & haptics**.
3. Under Calls, slide **Ring vibration** to stop vibration.

Make your phone vibrate for calls

1. Go to [Settings](#) > **Sound & vibration**.
2. Tap **Vibration & haptics** and check that **Use vibration & haptics** is on .
3. Under Calls, select options:
 - For incoming calls, turn **Ring vibration** on . Optionally, turn **Vibrate first then ring gradually** on .
 - To feel a vibration when a call you make is answered, turn **Vibrate for answered calls** on .

Set notification vibration

1. Go to [Settings](#) > **Sound & vibration**.
2. Tap **Vibration & haptics** and check that **Use vibration & haptics** is on .
3. Under Notifications and alarms, turn **Notification vibration** on  or off .

Control alarm vibration

Turn vibration on/off for one alarm

1. In the Clock app, tap  by the alarm.
2. Check or uncheck **Vibrate**.

Turn vibration off for all alarms

1. Go to [Settings](#) > **Sound & vibration**.