

4. Tap the app to allow, and set notifications to allow .

You'll see selected apps under APPS THAT CAN INTERRUPT. To change which notifications can interrupt, tap the app in the list.

Allow alarms and other interruptions

Alarms and media sounds are allowed by default, but you can turn them off. You can also allow touch sounds, reminders, and calendar events to send notifications.

1. Go to [Settings](#) > **Sound & vibration** > **Do Not Disturb**.

Or, in quick settings, touch & hold .

2. Tap **Alarms & other interruptions**.
3. Turn interruptions on  or off .