

Allow notifications to open apps in freeform

In addition to the sidebar, you can set apps to open in freeform mode from your notifications.

1. Go to **Settings** > **Gestures** > **Sidebar**.
2. Tap  at the bottom of the screen, then tap  (More settings) at top.
3. Turn **Open notifications in freeform** on .