

Customize the sidebar

Change apps in sidebar

1. On the sidebar, tap .
Or, go to **Settings** > **Gestures** > **Sidebar** > .
2. Customize the menu:
 - To rearrange apps, touch & hold an app, then drag it.
 - To remove an app, tap  or unmark its checkbox.
 - To add an app, tap it or mark its checkbox.
 - Tap  again to choose how apps open from the sidebar.

Change how apps open

For easy multitasking, set apps to open in resizable freeform windows you can drag around the screen, or set them to open in full screen.

1. On the sidebar, tap .
Or, go to **Settings** > **Gestures** > **Sidebar** > .
2. Tap  > **Open apps**.
3. Select whether to open them **In freeform** or **In full screen**.

When you're using apps:

- To see an app in a different mode (freeform or full screen), drag it from the sidebar to the center of the screen.
- To see an app in [split screen](#), drag it to the top or bottom of the screen.

Allow notifications to open apps in freeform

In addition to the sidebar, you can set apps to open in freeform mode from your notifications.

1. Go to **Settings** > **Gestures** > **Sidebar**.
2. Tap  at the bottom of the screen, then tap  (More settings) at top.
3. Turn **Open notifications in freeform** on .

About the Gametime sidebar

If you use Gametime, it has its own sidebar menu that opens apps. You [set up the apps for that menu separately](#).