

Use one-handed mode

Want to use one thumb to navigate your phone? Turn on One-handed mode.

This mode is only available if you're [using Gesture navigation](#).

Set it up

1. Go to [Settings](#) > **Gestures**.
2. Tap **One-handed mode** and turn it on .
3. Choose what should happen when you swipe down:
 - To move the top of the screen into reach of your thumb, select **Pull screen into reach**.
 - To see your notifications and quick settings, touch **Show notifications**.
4. To add , which you can touch instead of swiping down, turn **One-handed mode shortcut** on .

Use it

Move top of screen down where your thumb can reach

Swipe down near the bottom edge of the screen. Or tap  if you turned on the shortcut.



To exit this view:

- Swipe up from the bottom of the screen
- Tap anywhere above the app
- Tap 

See your notifications and quick settings

To see notifications and quick settings, swipe down from the bottom edge of the phone *once* or tap  *once*.

To see all quick settings, swipe down from the bottom edge of the phone *twice* or tap  *twice*.