

Turn it off or remove

If you want to remove  but still be able to swipe down near the bottom edge of the screen, go to **Settings** > **Gestures** > **One-handed mode** and turn **One-handed mode shortcut** off .

To turn off the gesture and remove :

1. Go to **Settings** > **Gestures**.
2. Tap **One-handed mode** and turn it off .