
Customize Power button gesture

You can customize the Power button, controlling what happens when you press it twice and when you press & hold it.

Choose what happens when you press Power twice

1. Go to [Settings](#) > **Gestures**.
2. Tap **Double press power key**.
3. Choose if you want to open the camera or to [start a voice command](#). If you don't want anything to happen, choose **None**.

Choose what happens when you press & hold Power

1. Go to [Settings](#) > **Gestures**.
2. Tap **Press & hold power button**.
3. Choose what you want the gesture to do:
 - To start a [voice command](#), select **Digital assistant**.
 - To see the Power menu for turning off or restarting the phone, or going into [Lockdown mode](#) or [Emergency mode](#), select **Power menu**.

If you select a choice other than **Power menu**, then to see the Power menu for turning off and restarting, you'll need to press the **Power + Volume up** buttons simultaneously.

4. To adjust how long you need to press & hold to start the selected action, move **Press & hold duration**.