

Use Battery saver

Battery saver helps extend battery life until your next charge. Your phone can prompt you to activate it when the battery is low, or you can enable it anytime. Choose between Standard battery saver and Maximum battery saver.

When Battery saver is on

When the phone is in Battery saver mode, you'll see  in the status bar.

Standard battery saver

When you use Standard battery saver, your phone will:

- Turn on Dark theme (You can [turn it off](#), but that uses more battery.)
- Lower the [refresh rate](#)
- Turn off [Live Caption](#)
- Wait until you use an app to refresh its content, like email or news
- Stop apps from doing things in the background (like listening for you to say “Hey Google”)
- Stop using Location services when your screen is off

Maximum battery saver

Maximum battery saver makes the same adjustments to your phone as Standard battery saver, and more.

Maximum battery saver will pause all apps and their notifications, except for these essential apps:

-  Clock
-  Messages
-  Settings

You can [assign other apps to be essential](#). For all other (non-essential) apps, the icons appear gray, and you can't use them until you switch to Standard battery saver or turn Battery saver off.

Maximum battery saver will also:

- Disable [gestures for controlling your phone](#)
- Disable live wallpapers
- Turn off work profile
- Stop [tethering and turn off hotspot](#)
- Stop Wi-Fi and Bluetooth scanning
- Set screen timeout to 15 seconds