

Adjust settings for Maximum battery saver

To adjust how Maximum battery saver works:

1. Open quick settings, then touch & hold .
2. Next to **Maximum battery saver**, tap .
3. Adjust settings:
 - To optimize battery savings based on how you're using the phone (device workload and temperatures), turn **Adaptive performance** on . This will lower screen brightness, adjust CPU frequency, and turn on low power mode as needed.
 - 5G uses more battery than 4G. If 5G isn't essential, enable  **Turn off 5G** to restrict it until you switch to **Standard battery saver** or turn **Battery saver** off .
 - Essential apps will always run. Non-essential apps are greyed out, so you can't open them, and you won't get notifications. You can add apps to the list of essential apps. However, this degrades battery savings. Beside an app, tap  to move it to **Essential apps**, or tap  to move it to non-essential apps.

Turn low-battery reminders on/off

1. Open quick settings, then touch & hold .
2. Tap **Schedule and reminders**.
3. Turn **Battery saver reminders** on  or off .