

Set a screen lock

You can set up a screen lock to secure your phone. Each time you turn on your phone or [turn on the screen](#), you'll be asked to unlock it.

Set or change screen lock

1. Go to [Settings](#) > **Security & privacy**.
2. Tap **Device unlock**.
3. Tap **Screen lock** and select the [type of lock](#) you want.

Some lock options aren't available if you added a [VPN](#) or a work (corporate) email account to your phone.

Tip: After you set up a pattern, PIN, or password, you can [set up fingerprint security](#) to unlock your phone with the fingerprint sensor.

Screen lock types

No lock:

- **None:** This gives no protection, but you can quickly access your home screen.
- **Swipe:** Swipe  up. This prevents accidental dialing but doesn't secure the phone.

Standard lock:

- **Pattern:** Draw a pattern on a grid.
- **PIN:** Enter a four to sixteen digit numeric code. Longer PINs are more secure.
- **Password:** Enter four to sixteen letters, digits, or symbols for the password. A long, strong password is the most secure option.

Biometrics:

- [Unlock with your face](#)
- [Unlock with your fingerprint](#)

You must set up one of the 3 standard locks in order to use biometrics.

Unlock or lock automatically

If you're using a PIN, password, or pattern, you can:

- Prevent repetitive unlocking by [keeping your phone unlocked](#) when you're at a defined place, connected to a defined Bluetooth device, or carrying the phone.
- [Instantly lock your phone](#) when you move out of range of a defined place, disconnect from a defined Bluetooth device, or disconnect from a defined Wi-Fi network. No need to remember to manually lock your screen or wait for the full [time before locking](#).