

- Reset options

The screen also has to be unlocked before Google Assistant can do anything related to those features.

1. Open the  **Moto Secure** app.

Or, go to **Settings > Security & privacy > Device unlock** and tap  next to **Screen lock**.

2. Tap **Lock Network and security**, then:

- For best protection if your phone is lost or stolen, turn it on .
- If you don't need higher security and want to access these features in quick settings without unlocking, turn it off .

Hide your pattern or PIN

You can hide your PIN or pattern to prevent others from viewing it when you unlock your screen. If you use a PIN, you can scramble the order of the numbers on the pad.

If you're using a [pattern screen lock](#), make it more secure by hiding finger traces on the screen when you draw:

1. Open the  **Moto Secure** app and tap **Security & privacy**.

Or, go to **Settings > Security & privacy**.

2. Tap **Device unlock**.
3. Next to **Screen lock**, tap .
4. Tap **Make pattern visible** off .

If you're using a [PIN screen lock](#), make it harder for someone to see the PIN you enter by scrambling the order of the numbers on the PIN pad:

1. Open the  **Moto Secure** app and tap **Security & privacy**.

Or, go to **Settings > Security & privacy**.

2. Tap **Device unlock**.
3. Next to **Screen lock**, tap .
4. Turn **PIN pad scramble** on .

Hide passwords

To control whether characters briefly display when you enter a password to unlock your phone or log into websites and apps:

1. Open the  **Moto Secure** app and touch **Privacy controls**.

Or, go to **Settings > Security & privacy > Privacy**.

2. Turn **Show passwords** off .