

Prevent repetitive unlocking

If you find yourself unlocking over and over, use Google's Extend Unlock to bypass the [screen timeout](#) and keep your phone unlocked when you're in more secure circumstances such as:

- At a trusted place like home, where you're not concerned about others accessing your phone
- When you're connected to a trusted Bluetooth device like a car audio system or headphones
- When you're carrying the phone around with you

To set it up:

1. Go to [Settings](#).
2. Tap **Security & privacy** > **More security & privacy** > **Extend Unlock**.

If you don't see Extend Unlock, try the following:

- Update Google Play services. In the Google Search widget on your home screen, search for "Google Play services", then tap the app to open it.
 - Go to **Settings** > **Security & privacy** > **More security & privacy** > **Trust agents** and enable **Extend Unlock**.
3. Unlock your phone.
 4. Adjust settings:
 - To remain unlocked when you're at a trusted place like home, tap **Trusted places**. Tap , drag the screen so the location pin is in the right place, then tap  to select the location.
 - To remain unlocked when you're connected to one of your Bluetooth devices, tap **Trusted devices**, then tap the name of the device. If you haven't paired any devices yet, tap **Pair new device**.
 - To remain unlocked when you're carrying your phone around, tap **On-body detection** and turn it on .

For more help with Extend Unlock, see [Google's help](#).