

Remove apps

1. Open  **Secure folder** and unlock it.
2. Touch & hold the app icon, then tap **Remove app**.

Control notification content from secure apps

You can [turn sensitive lock screen notifications on or off entirely](#) for all apps on your phone.

But when you add apps to Secure folder, you get more control over their sensitive notifications and can set them to:

- Show app icon, app name, and message content
- Show just the app icon and name
- Don't show notifications

To adjust notifications from secure apps:

1. Open  **Secure folder** and unlock it.
2. Tap  > **More settings** > **Notification Manager**.
3. Choose how you want to handle notifications from your secure apps.

Change the folder's lock and timeout

When you set up the folder, you created its lock. You can change the lock at any time. You can also change how long the folder stays unlocked.

Change the PIN/password/pattern

1. Open  **Secure folder** and unlock it.
2. Tap  and then **Authentication settings** > **Change lock** and unlock again.
3. Choose a lock type and set it up.
 - **Pattern:** Draw a pattern on a grid.
 - **PIN:** Enter a four to sixteen digit numeric code. Longer PINs are more secure.
 - **Password:** Enter four to sixteen letters, digits, or symbols. A long, strong password is the most secure option.

Set amount of time folder stays unlocked

Your secure folder automatically locks after a period of inactivity. You can increase or decrease the amount of time it can remain inactive before it locks.

1. Open  **Secure folder** and unlock it.
2. Tap  > **More settings** > **Secure folder timeout**.
3. Select a duration.