

To adjust keyboard sounds or vibration:

1. On the top row of the keyboard, tap .
2. Tap **Preferences**.
3. To adjust vibration:
 - Turn **Haptic feedback on keypress** off or on.
 - If on, tap **Vibration strength on keypress** and move the slider.
4. To adjust sounds:
 - To hear sounds when you type, turn **Sound on keypress** on .
 - To adjust how loud the sounds are, tap **Volume on keypress**.

Disable glide typing

With [glide typing](#), you drag your finger over the letters in a word. If you want to turn this off and only use multi-touch typing:

1. On the top row of the keyboard, tap .
2. Tap **Glide typing**.
3. Turn **Enable glide typing** off .

Limit or turn off suggestions

1. On the top row of the keyboard, tap .
2. Tap **Text correction**.
3. Adjust settings:
 - If you don't want predictions based on your previous word, turn **Next-word suggestions** off . You will only see [suggestions](#) for the current word you're typing.
 - If you don't want ANY suggestions, turn **Show suggestion strip** off .
 - You can also turn off (or on) offensive word blocking and suggestions for emoji, stickers, and information from Contacts.

Turn off auto-correction

1. On the top row of the keyboard, tap .
2. Tap **Text correction**.
3. If you don't want words corrected while you type, turn **Auto-correction** off .